



# SFC-200 SERIES LCD FIRE ALARM PANEL



# INSTALLATION INSTRUCTIONS



# Contents

---

<b>Industry Canada and FCC Notice .....</b>	<b>1</b>
<b>Introduction .....</b>	<b>2</b>
Overall Features .....	2
<b>Conventions .....</b>	<b>3</b>
Circuits .....	3
Zone .....	3
Events .....	3
Wiring Styles .....	3
<b>System Components .....</b>	<b>4</b>
Main Fire Control Panel .....	4
Relay Module: 12 Relays .....	5
Relay Modules: Six Relays .....	5
Polarity reversal/city tie .....	5
Remote Annunciator .....	6
Smart Relay Module .....	6
Input Class A converter: Six Circuits.....	6
Output Class A converter: four circuits .....	7
Output Class A converter: two circuits .....	7
Active end-of-line .....	7
SRAM-216 Remote Annunciator.....	7
Additional Fire Alarm System Accessories .....	7
<b>Mechanical Installation.....</b>	<b>8</b>
Installing the Enclosure.....	8
Installing the Adder Modules.....	11
<b>DIP Switch and Jumper Selections for Main Board and Adder Modules .....</b>	<b>13</b>
Main Fire Alarm Board .....	13
SICA-206 Input Class-A Converter Adder Module.....	15
SOCA-204/202 Output Class-A Converter Adder Module .....	16
Relay Adder Modules (Models SRM-212 and SRM-206) .....	16
SRM-206 Six Relay Adder Module .....	17
Polarity Reversal and City Tie Module (Model SPR-200) .....	18
<b>Field wiring .....</b>	<b>19</b>
Main Fire Alarm Board Field Wiring .....	19
Relay Adder Module Wiring .....	23
Polarity Reversal and City Tie Module (SPR-200) Wiring.....	24
Power supply connection.....	24
Wiring Tables and Information .....	25
Four-Wire Smoke Power (regulated) .....	26
Supervised Auxiliary Power (regulated).....	26
Auxiliary Power (unregulated).....	26
<b>System Checkout .....</b>	<b>27</b>
Before turning the power "ON" .....	27
Power-up procedure .....	27
Troubleshooting .....	27
<b>Indicators, Controls and Operations .....</b>	<b>28</b>
Common Indicators.....	29
Common Controls .....	29
Common Relays .....	30
Circuit Types .....	31
Evacuation codes.....	32
Fire Alarm Operation.....	33
<b>Supported Protocols/Devices .....</b>	<b>34</b>

Synchronous Strobes.....	34
System Sensor's i3 Devices.....	34
<b>Configuration .....</b>	<b>36</b>
Entering the Passcode .....	36
Command Menu.....	37
1. SFC-200 CONFIG (Command-Menu).....	38
2. Config Info (Command-Menu).....	46
3. Set Time (Command-Menu).....	47
4. Set Password (Command-Menu).....	48
5. View Event Log (Command-Menu) .....	48
6. Clear Event Log (Command-Menu) .....	49
7. Walk Test (Command-Menu) .....	50
8. i3 Loop Test (Command-Menu) .....	51
9. Dialer Config (Command-Menu) .....	52
10. Test Dialer (Command-Menu).....	57
11. Bypass Det Ckt (Command-Menu) .....	59
12. Bypass NAC Ckt (Command-Menu) .....	59
13. Aux. Disconnect (Command-Menu) .....	59
14. Exit (Command-Menu) .....	60
<b>Appendix A: Compatible Receivers.....</b>	<b>65</b>
<b>Appendix B: Reporting .....</b>	<b>66</b>
Ademco Contact-ID.....	66
Security Industries Association SIA-DCS.....	67
<b>Appendix C: Specifications.....</b>	<b>68</b>
<b>Appendix D: Power Supply and Battery Calculations (Selection Guide).....</b>	<b>69</b>
<b>Warranty.....</b>	<b>70</b>

# List of Figures and Tables

---

## Figures

Figure 1: Box dimensions, surface mount.....	8
Figure 2: SFC-201-12DDR Box dimensions, semi-flush mounting with trim ring.....	9
Figure 2A: SFC-200-6DDR/6DR Box dimensions, mounting and trim ring.....	10
Figure 3: Installation of Adder Modules for FA-301 LCD Panels .....	11
Figure 4: Installation of Adder Modules for SFC-200 LCD Panels.....	12
Figure 5: Main Fire Alarm Board DIP switch and jumper settings for FA-301 LCD Panels .....	13
Figure 6: Main Fire Alarm Board DIP switch and jumper settings for SFC-200 LCD Panels ....	14
Figure 7: SICA-206 Input Class-A Converter Adder Module.....	15
Figure 8: SOCA-204/202 Output Class-A Converter Adder Module .....	16
Figure 9: SRM-212 twelve relay adder module.....	16
Figure 10: SRM-212/206 Relay programming .....	17
Figure 11: SRM-206 six relay adder module.....	17
Figure 12: Polarity reversal and city tie module .....	18
Figure 13: Initiating circuit – Class B or Style B wiring.....	19
Figure 14: Initiating circuit– Class A or Style D wiring.....	20
Figure 15: Indicating circuit – Class B or Style Y wiring.....	20
Figure 16: Indicating circuit – Class A or Style Z wiring.....	21
Figure 17: Four-wire smoke detector wiring.....	21
Figure 18: Dialer wiring .....	22
Figure 19: Relay per zone (SRM-212) Terminal connection.....	23
Figure 20: Relay per zone (SRM-206) Terminal connection.....	23
Figure 21: Polarity reversal and city tie module terminal connection .....	24
Figure 22: Power supply connection .....	25
Figure 23: LCD Display and control buttons .....	28
Figure 24: Evacuation Codes.....	32
Figure 25: SFC-200 Configuration .....	36

## Tables

Table 1: Connectors and Jumpers on the Main Fire Alarm Board.....	14
Table 2: SPR-200 jumper settings .....	18
Table 3: Initiating Circuit Wiring .....	25
Table 4: Indicating Circuit Wiring .....	26



# Industry Canada and FCC Notice

## Notice for all SFC-200 Series Built-In UDACTs Sold in Canada

Summit's **SFC-200 SERIES BUILT-IN UDACT Communicator** described in this manual is listed by Underwriters Laboratories Canada (ULC) for use in slave application in conjunction with a Listed Fire Alarm Control Panel under Standard ULC-S527 (Standard for Control Units for Fire Alarm Systems) and ULC/ORD-C693-1994 (Central Station Fire Protective Signalling Systems and Services). These Communicators should be installed in accordance with this manual; the Canadian / Provincial / Local Electrical Code; and/or the local Authority Having Jurisdiction (AHJ).

### Industry Canada Notice

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alteration made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment. Users should ensure for their own protection that the **Earth Ground** connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This is necessary both for proper operation and for protection.



**CAUTION:** Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate

## Notice for all SFC-200 Series Built-in UDACTs Sold in the U.S.A.



**Note:** The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

The REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

Summit's **SFC-200 SERIES BUILT-IN UDACT Digital Communicator** described in this manual is listed by Underwriters Laboratories Inc. (ULI) for use in slave application in conjunction with a Listed Fire Alarm Control Panel under Standard 864 (Control Units for Fire Protective Signalling Systems). These Communicators comply with the National Fire Protection Association (NFPA) performance requirements for DACTs and should be installed in accordance with NFPA 72 Chapter 4 (Supervising Station Fire Alarm System). These Communicators should be installed in accordance with this manual; the National Electrical Code (NFPA 70); and/or the local Authority Having Jurisdiction (AHJ).

### FCC Notice

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the telco transformer of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company. This equipment is capable of seizing the line. This capability is provided in the hardware.

**Type of Service:** The **Communicator** is designed to be used on standard device telephone lines. It connects to the telephone line by means of a standard jack called the USOC RJ-11C (or USOC FJ45S). Connection to telephone company provided coin service (central office implemented systems) is prohibited. Connection to party lines service is subject to state tariffs.

**Telephone Company Procedures:** The goal of the telephone company is to provide you with the best service it can. In order to do this, it may occasionally be necessary for them to make changes in their equipment, operations or procedures. If these changes might affect your service or the operation of your equipment, the telephone company will give you notice, in writing, to allow you to make any changes necessary to maintain uninterrupted service.

In certain circumstances, it may be necessary for the telephone company to request information from you concerning the equipment which you have connected to your telephone line. Upon request of the telephone company, provide the FCC registration number and the ringer equivalence number (REN); both of these items are listed on the equipment label. The sum of all of the REN's on your telephone lines should be less than five in order to assure proper service from the telephone company. In some cases, a sum of five may not be usable on a given line.

**If Problems Arise:** If any of your telephone equipment is not operating properly, you should immediately remove it from your telephone line, as it may cause harm to the telephone network. If the telephone company notes a problem, they may temporarily discontinue service. When practical, they will notify you in advance of this disconnection. If advance notice is not feasible, you will be notified as soon as possible. When you are notified, you will be given the opportunity to correct the problem and informed of your right to file a complaint with the FCC. Contact your telephone company if you have any questions about your phone line. In the event repairs are ever needed on the Communicator, they should be performed by Summit Systems Technologies or an authorized representative of Summit Systems Technologies. For information contact Summit Systems Technologies at the address and phone numbers shown on the back page of this document.

# Introduction

---

Summit's **SFC-200** Series Fire Alarm Control Panel is a Digital Signal Processor (DSP) based fire panel. The SFC-200 provides a maximum of 12 supervised Class B or A (Style B or D) Initiating circuits, and maximum of four supervised Class B or A (Style Y or Z) indicating circuits. All circuits are supervised for opens and ground faults, and indicating circuits are supervised for shorts. Optional modules include Relay, Polarity Reversal and City Tie and Class A Converters for initiating and indicating circuits. Semi-flush or surface mountable enclosures can be used for retrofits and on new installations.



**Note:** Installation of the SFC-200 series fire alarm control panel should be in accordance with Canadian Electrical Code Part 1, ULC-S524 installation of Fire Alarm System, National Electrical Code NFPA 70 and NFPA 72. Final acceptance subject to the Local Authority Having Jurisdiction (AHJ).

## Overall Features

- Basic unit has six Class B (Style B) initiating circuits, which may be configured as Class A (Style D) using input Class A converter adder module. Each initiating circuit can be configured as Alarm, Verified Alarm, Water flow Alarm, Sprinkler Alarm, Latching or Non-Latching Supervisory, Monitor or Trouble-Only circuits.
- Basic unit has two Power Limited Class B (Style Y) indicating circuits. Each indicating circuit may be configured as Class A (Style Z) using output Class A converter adder module. Each indicating circuit may be configured as Silenceable signal, non Silenceable signal, Silenceable strobe, non Silenceable strobe. The audible signal may be Steady, Temporal Code, California Code, or March Time.
- Each initiating and indicating circuit can be individually disconnected via the keypad and LCD display with Password Access.
- Configurable Signal Silence Inhibit, Auto Signal Silence, and One-Man Walk Test.
- Four-wire resettable smoke power supply 300mA maximum.
- Relay Contacts for Common Alarm, Common Supervisory and Common Trouble all non-disconnect-able and Auxiliary Alarm Relay (disconnectable).
- RS-485 Interface for RA-1000 Series Remote Multiplex Annunciators, LCD Annunciators and Smart relay adder.
- Optional Modules for additional Relay Circuits, City Tie and Polarity Reversal Signaling.
- Extensive transient protection.
- With or without built-in UDACT (Digital Alarm Communicator Transmitter).
- Easy configuration of the panel using front LCD display and keypad.
- Remote dial up (with built-in UDACT version) for event log checking and/or configuration changing.
- Laptop programmer for direct configuration changing and log checking.

# Conventions

---

## Circuits

Refers to an actual electrical interface for Initiating (Detection) and Indicating (Signal) or Relays

## Zone

Is a logical concept for a Fire Alarm Protected Area, and will consist of at least one Circuit.

Often the terms Zone and Circuit are used interchangeably, but in this Manual the term Circuit is used.

## Events


There are events associated with every initiating, indicating and common circuit of the fire panel displayed via the LCD.

## Wiring Styles


Initiating and indicating circuits are Class B (Style B and Y). Changing the initiating circuits to Class A requires an SICA-206 adder board which will convert SIX initiating zones from Class B (Style B) circuits to Class A (Style D). This is done without penalizing the number of circuits, which remains the same as in Class B (Style B). Changing the indicating circuits to Class A requires an SOCA-204 adder board which will convert FOUR indicating zones from Class B (Style Y) circuits to Class A (Style Z) or an SOCA-202 adder board which will convert TWO indicating zones from Class B (Style Y) circuits to Class A (Style Z).

# System Components


## Main Fire Control Panel

	Model	Description
	SFC-201-12DDR	<p>Twelve-Zone Fire Alarm Control Panel with LCD display and dialer (red door, black box). 12 Class B (Style B) Initiating circuits, and four Power Limited Class B (Style Y) Indicating circuits (up to 1.70 amperes each, 5 amperes total). Two six zone <b>SICA-206 Input Class A Converter</b> adder modules may be used for Class A (Style D) wiring of Initiating circuits. One <b>SOCA-204 Output Class A Converter</b> adder module may be used for Class A (Style Z) wiring of the Indicating circuits. The SFC-201-12DDR contains Common Alarm, Common Supervisory &amp; Common Trouble Relays, auxiliary alarm relay (disconnectable), an RS-485 Interface for Remote Annunciators and a Resettable Four Wire Smoke Detector Power Supply. The unit has a dialer on the main board. Used with BA-110 (10 ampere-hour) (Sota Enerotech model SA12120) batteries (two are required).</p>
	SFC-200-6DDR	<p>Six-Zone Fire Alarm Control Panel with LED display and dialer (Red enclosure). Six Class B (Style B) Initiating circuits, and two Power Limited Class B (Style Y) Indicating circuits (up to 1.70 amperes each, 5 amperes total). One six zone <b>SICA-206 Input Class A converter</b> adder module may be used for Class A (Style D) wiring of Initiating circuits. One <b>SOCA-202 Output Class A Converter</b> adder module may be used for Class A (Style Z) wiring of the Indicating circuits. The SFC-200-6DDR contains Common Alarm, Common Supervisory &amp; Common Trouble Relays, auxiliary alarm relay (disconnectable), an RS-485 Interface for Remote Annunciators and a Resettable Four Wire Smoke Detector Power Supply. The unit has a dialer on main board. Used with BA-110 (10 ampere-hour) (Sota Enerotech model SA12120) batteries (two required).</p>
	SFC-200-6DR	<p>Same as the SFC-200-6DDR except without dialer.</p>


### Relay Module: 12 Relays

	Model	Description
	<b>SRM-212</b>	Twelve-relay adder module


### Relay Modules: Six Relays

	Model	Description
	<b>SRM-206</b>	Six-relay adder module


### Polarity reversal/city tie

	Model	Description
	<b>SPR-200</b>	Polarity Reversal and/or City tie Module


## Remote Annunciator

	Model	Description
	SRAM-200LCDR	Remote Annunciator Module, LCD display, red enclosure


## Smart Relay Module

	Model	Description
	SSR-212R	Smart Relay Module (12 relays) with red enclosure.


## Input Class A converter: Six Circuits

	Model	Description
	SICA-206	Input Class A converter Module (six circuits). This module has built in Active End-of-Line resistors.

### Output Class A converter: four circuits


	Model	Description
	SOCA-204	Output Class A converter module (four circuits)

### Output Class A converter: two circuits


	Model	Description
	SOCA-202	Output Class A converter module (two circuits)

### Active end-of-line

The SELR-200 are power-saving End-of-Line resistors that eliminate the need for an additional battery cabinet or larger batteries in order to meet the 60 hour standby requirement.

	Model	Description
	SELR-200	Active end-of-line resistor without plate

### SRAM-216 Remote Annunciator

	Model	Description
	SRAM-216	16 Zone remote annunciator

### Additional Fire Alarm System Accessories

Model: **SRAM-208** Eight Zone Remote Annunciator (ULC and ULI Approved)


Model: **SRTI-200** Remote Trouble Indicator (ULC and ULI Approved)

# Mechanical Installation


## Installing the Enclosure

Install the SFC-200 Series Fire Alarm Panel enclosure as shown below for the twelve zone models. Mount enclosure surface mount using the four mounting holes, as shown and the screws provided. The backbox may be semi-flush mounted using the trim ring model FA-UNIV-TRB (BLACK), see Figure 2. Remove the door (also disconnect the ground strap), the dead front (if supplied) and mount the backbox in between the studs. Place the trim ring around the backbox. The trim ring is glued in place to the wall surface, after the wall is finished. Replace the front door and ground strap.


**Figure 1: Box dimensions, surface mount**




**Figure 2: SFC-201-12DDR Box dimensions, semi-flush mounting with trim ring**



The figure below shows a cross-section of the semi-flush mounted backbox and the trim ring. Make sure to **allow a minimum depth of 1"** above the wall surface for proper door opening.




**Figure 2A: SFC-200-6DDR/6DR Box dimensions, mounting and trim ring**



## Installing the Adder Modules

SFC-200 Series Fire Alarm panels come pre-assembled with all components and boards except for Adder Modules. Module installation locations are shown below. Refer to *Figure 4* for Jumper or DIP Switch settings and see *Wiring Tables and Information* section for wiring information.

**Figure 3: Installation of Adder Modules for SFC-201 LCD Panels**







# DIP Switch and Jumper Selections for Main Board and Adder Modules

## Main Fire Alarm Board

Figure 5: Main Fire Alarm Board DIP switch and jumper settings for SFC-201 LCD Panels



**Figure 6: Main Fire Alarm Board DIP switch and jumper settings for SFC-200 LCD Panels**




**Table 1: Connectors and Jumpers on the Main Fire Alarm Board**

P5	Cable from P1 of the <b>SPR-200 Polarity Reversal and City Tie Module</b> connects here. Otherwise not used.
P6	Cable from connector P1 of the <b>SRM-212 or SRM-206 Relay Adder Module</b> connects here. Otherwise not used.
JW1	On the Main Fire Alarm Module, this jumper must be removed if a <b>SPR-200 Polarity Reversal and City Tie Module</b> is installed.
JW2	Remove this jumper if a <b>SRM-212 or SRM-206 Relay Adder Module</b> is used.
JW3	Removed all the time.
JW4	Normally open. Place jumper here and power down (AC and Batteries) then power back to revert to default password. After reset remove the jumper. Leave normally open.
JW5	Normally open to <b>BLOCK remote</b> configuration via modem, PC with a UIMA converter module or using the LCD and keys at the panel. Place jumper here to <b>ALLOW</b> any type of configuration.
JW6	Not used, open (not available on SFC-200 LCD panels).
JW7	Not used, open.



## SOCA-204/202 Output Class-A Converter Adder Module

**Figure 8: SOCA-204/202 Output Class-A Converter Adder Module**



Indicating circuits must be wired from the SOCA-204/202 to the main Fire Alarm board. For example indicating circuit 1 positive (red wire) and negative (black wire) is wired from the Class A converter module to the positive and negative terminals of Indicating circuit 1 on the Main Fire Alarm board.


The actual indicating zone is wired from the SIGNAL OUT positive and negative to the signaling devices and then wired back to the SIGNAL RET positive and negative.

## Relay Adder Modules (Models SRM-212 and SRM-206)

### SRM-212 Twelve-Relay Adder Module

The ribbon cable from P1 of the SRM-212 is connected to P6 on the Main Fire Alarm Board. The jumpers located above each relay on the SRM-212 are used to configure the relays. The jumpers located below the relays are used to select either normally open contacts or normally closed contacts.

**Figure 9: SRM-212 twelve relay adder module**



**P1:** Cable from **SRM-212 Relay Adder Module** connects to **P6** on the Main Fire Alarm Board.


### Programming the relays

A typical relay circuit is shown below in *Figure 8* with the jumper locations and descriptions.



**Note:** Relay programming should be done before installing the board


**Figure 10: SRM-212/306 Relay programming**



### SRM-206 Six Relay Adder Module

Cable from P1 of the SRM-206 is connected to P6 on the Main Fire Alarm Board. The jumpers located above each relay on the SRM-206 are used to configure the relays. The jumpers located below the relays are used to select either normally open contacts or normally closed contacts.

**Figure 11: SRM-206 six relay adder module**



**P1:** Cable from SRM-206 Relay Adder Module connects to P6 on the Main Fire Alarm Board.

### Programming the relays


See explanation in Figure 8.



**Note:** Relay programming should be done before installing the board

## Polarity Reversal and City Tie Module (Model SPR-200)

**Figure 12: Polarity reversal and city tie module**



The following hardware configuration must be performed before installing the SPR-200

**Table 2: SPR-200 jumper settings**

P1	Cable connects to <b>P5</b> on the <b>Main Fire Alarm Board</b>
JW1	Cut this jumper for Trouble transmission. When this jumper is cut and a system trouble occurs, the designated terminals will transmit a "zero volts" or "open" circuit. Please note that in normal condition, the terminals polarity is read exactly as labeled on the circuit board.
JW2	Cut this jumper for Trouble transmission of supervisory. When this jumper is cut and a supervisory trouble occurs, the designated terminals will transmit a "zero volts" or "open" circuit. Please note that in normal condition, the terminals polarity is read exactly as labeled on the circuit board.
P2 & JW4	Not used with SFC-200 Fire Alarm Panel. Jumper JW4 remains on board.

The Alarm Transmit signal to the SPR-200 can be programmed to turn OFF when signal silence is active. This allows the City Tie Box to be manually reset. On subsequent alarms the silenceable signals will resound and the City Tie Box will be retriggered. See Configuration section for more information.

The Trouble Transmit signal to the SPR-200 can be programmed to delay AC power fail for 0, 8 or 18 hours if this is the only system trouble. See Configuration section.

# Field wiring

## Main Fire Alarm Board Field Wiring

Wire devices to the terminals as shown in the figures that follow. Refer to the Wiring Tables for wire gauges and to Appendix A for specifications.



**CAUTION:** Do not exceed power supply ratings.


### Initiating Circuit Wiring

Wiring diagrams for the initiating circuits are shown below. The panel supports Style B wiring for the initiating circuits and Style D wiring for the indicating circuits. The initiating circuits are supervised by a 3.9K End-of-Line Resistor or for power saving an Active-End-of-Line.




**Note:** According to Configuration, End-of-Line Resistors on initiating circuits must be all 3.9K ohms or all Active End-of-Line resistors.

**Figure 13: Initiating circuit – Class B or Style B wiring**



**Figure 14: Initiating circuit– Class A or Style D wiring**



**Note:** When using ICAC Class A Converter Adder Modules, always use Active End-of-Line resistors on all initiating circuits including those that are not converted to Class A.


**Indicating Circuit Wiring**

The SFC-200 Series Fire Alarm supports Class B (Style Y) and Class A (Style Z) wiring for its indicating circuits. Each circuit is supervised by a 3.9K End-of-Line resistor. Each indicating circuit provides up to 1.7 A, 5 A maximum total if no auxiliaries are used.




**Note:** An Active End-of-Line resistor CANNOT be used with any indicating circuits. Always use 3.9K End of Line resistors for indicating circuits.

**Figure 15: Indicating circuit – Class B or Style Y wiring**




**Figure 16: Indicating circuit – Class A or Style Z wiring**



**Four Wire Smoke Detector Wiring**


**Figure 17: Four-wire smoke detector wiring**



### Dialer Wiring

If you have Fire Alarm Panel Models SFC-201-12DDR or SFC-200-6DDR there is a dialer on board and terminals marked Line 1 and Line 2 must be wired as shown in Figure 18 below. The dialer circuitry also allows for remote configuration using a PC.


**Figure 18: Dialer wiring**




## Relay Adder Module Wiring

Wire relays on the relay adder modules SRM-212 and SRM-206 as shown in Figures 17 and 18.

**Figure 19: Relay per zone (SRM-212) Terminal connection**



**Figure 20: Relay per zone (SRM-206) Terminal connection**




## Polarity Reversal and City Tie Module (SPR-200) Wiring

Wire SPR-200 Polarity Reversal and City Tie Module (if used) as shown in *Figure 19*, below. See *Appendix A* for module specifications. Power Limited cable type FPL, FPLR or FPLP must be used.

For USA installation, the installer must use **Atlantic Scientific (Tel: 407-725-8000), Model #24544 Protective Device**, or similar **UL-Listed QVRG secondary protector**, as shown.

**Figure 21: Polarity reversal and city tie module terminal connection**



## Power supply connection

The power supply is part of the Main Chassis. The ratings are:


Type	Rating
Electrical Input rating	120VAC, 60Hz, 3A\ 240 VAC, 50 Hz, 1.5A main primary circuit breaker
Power supply total current	6A maximum
Battery fuse on Main module	10A Fuse, slow blow micro fuse

Wire as shown below in *Figure 20* using the proper wire gauge. See *Appendix A* for power supply specifications.



**CAUTION:** Do not exceed power supply ratings.

**Figure 22: Power supply connection**



**Wiring Tables and Information**

**Table 3: Initiating Circuit Wiring**

Wire gauge AWG	Maximum wiring run to last device	
	Feet	Meters
22	2990	910
20	4760	1450
18	7560	2300
16	12000	3600
14	19000	5800
12	30400	9200



**Notes:**

- For Class A the maximum wiring run to the last device is divided by two.
- Maximum loop resistance should not exceed 100 ohms.
- Maximum capacitance of 0.5uF total on each initiating circuit.

**Table 4: Indicating Circuit Wiring**

Total signal load in amperes	Maximum wiring run to last device								Max. loop resistance in ohms
	18 AWG		16 AWG		14 AWG		12 AWG		
	Feet	Meters	Feet	Meters	Feet	Meters	Feet	Meters	
0.06	2350	716	3750	1143	6000	1829	8500	2591	30
0.12	1180	360	1850	567	3000	915	4250	1296	15
0.30	470	143	750	229	1200	366	1900	579	6
0.60	235	71	375	114	600	183	850	259	3
0.90	156	47	250	76	400	122	570	174	2
1.20	118	36	185	56	300	91	425	129	1.5
1.50	94	29	150	46	240	73	343	105	1.2
1.70	78	24	125	38	200	61	285	87	1.0



**Notes:**

- For Class A wiring the resistance in ohms is multiplied by two.
- Maximum voltage drop should not exceed 1.8 volts.

**Four-Wire Smoke Power (regulated)**

4-wire smoke power is provided for 4-wire smoke detectors. This filtered supply is supervised, therefore a short will disconnect the power through the relay until the “RESET” key is pressed. This supply is rated at 22.3VDC regulated/300mA max/1V voltage drop maximum.

**Supervised Auxiliary Power (regulated)**

Supervised auxiliary power is used to power the remote annunciators and smart relay modules. This filtered circuit is supervised, therefore a short will disconnect the power through the relay until the “RESET” key is pressed. This supply is rated at 22.3VDC regulated/500mA max/1V voltage drop maximum.

**Auxiliary Power (unregulated)**

This unregulated supply is not supervised. This supply is rated at 24VDC/1.7A max. If there is a short on this circuit, the auxiliary power does not recover automatically when the short is removed. The main power must be disconnected, then reconnected and the panel reset to re-establish the auxiliary power supply.

# System Checkout

## Before turning the power “ON”

To prevent sparking, **do not connect** the batteries. Connect the batteries after powering the system from the main AC supply.

1. Check that all modules are installed in the proper location with the proper connections.
2. Check all field (external) wiring for opens, shorts, and ground.
3. Check that all interconnection cables are secure, and that all connectors are plugged in properly.
4. Check all jumpers and DIP switches for proper setting.
5. Check the AC power wiring for proper connection.
6. Check that the chassis is connected to **EARTH GROUND** (cold water pipe).

## Power-up procedure

After completing the System Checkout procedures outlined above,

7. Power up the panel. The "AC-ON" green LED and the “Common Trouble” LED should illuminate, and the buzzer should sound. Press the “System Reset” button. Since the batteries are not connected, the trouble buzzer should sound intermittently and the common trouble LED should flash.
8. Connect the batteries while observing correct polarity: the red wire is positive (+) and black wire is negative (-). All indicators should be OFF except for normal power "AC ON" green LED and green LED I47.



**Note:** Green LED I47 is illuminated when the system is normal. This LED indicates that the trouble relay is in normal standby condition.

9. Configure the Fire Alarm Control Panel as described in the Configuration section.


## Troubleshooting

Symptoms (as displayed on the LCD)	Possible Cause
Circuit Trouble	Normally when a circuit trouble occurs, the common trouble indicator will illuminate and trouble buzzer will sound. To correct the fault, check for open wiring on that particular circuit loop (as displayed on the LCD) or that the circuit has not been disconnected (or bypassed). <i>Disconnecting a Circuit will cause a system trouble (off-normal position).</i>
Remote Fail	Remote Fail will be indicated on the main LCD display for any failure reported by, or failure to communicate with a remote annunciator or other remote device.
Ground Fault	This panel has a <b>common ground fault detector</b> . To correct the fault, check for any external wiring touching the chassis or other Earth Ground connection.
Battery Trouble	Check for the presence of batteries and their conditions. Low voltage (below 20.4V) will cause a battery trouble. If battery trouble condition persists, replace batteries as soon as possible.
Common Trouble	If only a common trouble is indicated on the main panel and none of the above troubles exist, check the following for a possible fault: Check for any missing interconnection wiring. Check for any Module missing that was part of the Configuration. Check for improperly secured cabling.

## Indicators, Controls and Operations

Refer to Figure 23 below which shows the LCD Display, the Keypad and Control Button locations.

**Figure 23: LCD Display and control buttons**



The Main Display Panel on the Main Fire Alarm Control Board consists of:

- 5 common LED Indicators (under the LCD display)
- 5 Common Buttons (column left of key pad)

LED Indicators may be Amber, Red, or Green, and may illuminate continuously (steady), or at one of two Flash Rates.

- Fast Flash (Supervisory) - 120 flashes per minute, 50% duty cycle
- Trouble Flash (Trouble) - 20 flashes per minute, 50% duty cycle

## Common Indicators

### Buzzer

The Buzzer is activated by any of the following events:

<b>Fire Alarm:</b>	Steady
<b>Supervisory Alarm:</b>	Fast Flash
<b>Trouble:</b>	Trouble Flash Rate

If the Buzzer is turned ON in response to a Non-Latching Trouble or Supervisory, it will be turned OFF if the condition causing it goes away and there is no other reason for it to be ON.

### AC ON LED

The green AC ON Indicator will illuminate steadily as long as the main AC power is above minimum level. The indicator turns OFF when the level falls below the power fail threshold and the panel is switched to standby (battery) power.

### Alarm LED

The red Alarm Indicator will illuminate whenever the panel detects an alarm condition on any initiating circuit. Since all alarms are latched until the panel is reset, the Indicator will remain ON until then.

### Supervisory LED

The amber Supervisory Indicator turns ON steady when there is a Supervisory Alarm in the Panel caused by any Latching or Non-Latching Supervisory Circuit. The Indicator is turned OFF when all Non-Latching Supervisory Circuits are restored and there are no active Latching Supervisory Circuits. Latching Supervisory Alarms remain active until the Panel is reset.

### Trouble LED

The amber Trouble Indicator flashes at the Trouble Flash Rate when the panel detects any trouble condition. It turns OFF when all Non-Latching Troubles are cleared.

### CPU Fail LED

The amber CPU Fail LED Indicator flashes at the Trouble Flash Rate to indicate a microprocessor failure on the main board.

## Common Controls

### System Reset Button

The System Reset button resets the Fire Alarm Control Panel and all circuits. In particular, the system reset button does the following:

- Resets all Latching Trouble Conditions
- Resets all Initiating Circuits
- Resets 4-Wire Smoke Supply
- Turns off all Indicating Circuits
- Turns off Signal Silence
- Turns off Fire Drill
- Stops and resets all Timers
- Processes inputs as new events
- Does not affect Aux Disconnect

**Signal Silence Button**

Activation of the Signal Silence button when the panel is in alarm deactivates any Silenceable Indicating Circuits. Non-Silenceable Circuits are unaffected. Signals will resound upon any subsequent alarm. Subsequent operation of signal silence resounds all Silenceable signals. This button does not function during any configured Signal Silence Inhibit Timer period (see Configuration section). It also does not function if the Indicating Circuits are active as the result of a Fire Drill.

**Fire Drill Button**

The Fire Drill button activates all Non-Disconnected (un-bypassed) Indicating Circuits, but does not transmit any Alarms via the City Tie, Common Alarm Relay or Auxiliary Alarm Relay. Fire Drill activates the signals in the evacuation code programmed. For example in the Temporal Code, the signals will be pulsed ON for 0.5 seconds, OFF for 0.5 seconds in rounds of 3 and then pause for 1.5 seconds and repeat.

Fire Drill is cancelled by pressing the button again, or if the Panel goes into a real alarm.

**Lamp Test Button**

Activation of the Lamp Test button causes all front panel Indicators to steadily illuminate and turns the buzzer ON steady. If Lamp Test is active for more than 10 seconds, Common Trouble is activated. The Lamp Test will also show the panel type and software version on the LCD display if the button is held for at least 3 seconds.

**Buzzer Silence Button**

Activation of the Buzzer Silence button while the Buzzer is sounding silences the Buzzer. The Buzzer will resound if there is a subsequent event. Pressing the button when the Buzzer is not sounding has no effect.

**Common Relays****Common Alarm Relay**

The Common Alarm Relay activates when a general alarm sequence is activated. Since all alarm conditions are latched until system reset, the relay will remain ON until the alarm is cleared and the system is reset. The common alarm can be disconnected by aux disconnect (use Command Menu #12, as switch) if programmed to do so (see SFC-200 Config/Features 5 and 7).

**Common Supervisory Relay**

The Common Supervisory Relay activates when the common supervisory sequence is activated as the result of an alarm or any un-bypassed latching or non-latching supervisory circuit. The relay is turned OFF if all non-latching supervisory circuits are restored and there are no latching supervisory circuits active. The relay can be disconnected by aux disconnect (use Command Menu as switch) if programmed (see Configuration section). This Common Supervisory Relay will function the same way as a Common Alarm relay if programmed to (*see configuration menu/ SFC-200 Config/Feature 12*)).

**Common Trouble Relay**

The Common Trouble relay is activated when the common trouble sequence is activated as the result of the trouble condition being detected on the system. It is turned off when all troubles are cleared.



**Note:** Some troubles are latching once they are detected they remain active until system reset. In this case the common trouble indicator will also remain active until system reset. The common trouble is not bypassed by the auxiliary disconnect function.

**Auxiliary Alarm Relay**

The Auxiliary Alarm Relay functions the same way as the Common Alarm Relay in every respect except that it can be disconnected by auxiliary disconnect (via Command Menu/Item 12 which acts like a switch) with or without correlated relays if it is programmed to do so (see Configuration section). When configured (see Configuration section), the relay can also be disconnected if signal silence is active and reconnected if signal silence is deactivated.

## Circuit Types

### Initiating (Detection) Circuit Types

#### Non-Verified Alarm

A Non-Verified alarm is a “normal” type of alarm that can have pull stations, smoke detectors, or heat detectors attached to it. Activation of any of these devices will immediately result in an alarm condition in the Fire Alarm Control Panel. An Alarm condition causes the Common Alarm LED to illuminate red.

#### Verified Alarm

Verified Alarms are verified by a reset and timing procedure, and may include smoke detectors, heat detectors or pull stations. Activation of pull stations or heat detectors will result in an alarm condition in the Fire Alarm Control Panel within four seconds. Smoke detectors will be verified for a real alarm within 60 seconds, depending upon the startup time of the devices being used. If four seconds is too long a response time for pull stations, then wire them separately on a Non-Verified Alarm Circuit. An alarm condition causes the Common Alarm LED to illuminate red.

#### Water Flow Alarm (Water flow Sensors)

Water Flow Alarms are identical to normal Non-Verified Alarms except that any indicating circuits programmed to these circuits (all are by default) are Non-Silenceable. Also, if Water Flow Retard Operation is enabled, these circuits are sampled every one second. If ten samples are active within any 15-second interval, the Water flow Alarm is confirmed and processed. An alarm condition causes the Common Alarm LED to illuminate red.



**Note:** Do not use Retard Operation with any external retarding device; maximum retard may not exceed 120 seconds.

#### Sprinkler Alarm (for Sprinkler Flow Sensors)

Sprinkler Alarms are identical to normal Non-Verified Alarms unless Water flow retard operation is enabled. If Water Flow Retard Operation is enabled, then these circuits are sampled every one second. If ten samples are active within any 15-second interval, the Sprinkler Alarm is confirmed and processed. An Alarm condition causes the Common Alarm LED to illuminate red.



**Note:** Do not use Retard Operation with any external retarding device; maximum retard may not exceed 120 seconds.

#### Non-Latching Supervisory (For Supervisory Circuits)

An activation on these circuits will cause the amber Common Supervisory LED to illuminate. The buzzer will sound at fast rate. If the circuit activation is removed, the Supervisory condition will clear (as long as there are no other Supervisory conditions in the system) and the Circuit Status LED will turn off.

#### Latching Supervisory (For Supervisory Devices)

An activation on these circuits will cause the amber Common Supervisory LED to illuminate. The buzzer will sound at fast rate. If the circuit activation is removed, the Supervisory condition will NOT clear.

#### Monitor

This is a supervised general-purpose non-latching input used mainly for correlating to a relay circuit. No other system condition occurs as a result of its activation (short-circuit), although it is supervised for Trouble (open-circuit).

#### Trouble-Only

The Trouble-Only circuit monitors a Trouble Condition from an external device such as QX-5000 Audio System. Both open and short circuits generate a non-latching Trouble condition.

### Indicating (Signal) Circuits Types

#### Silenceable Signal

The Silenceable Signal circuit is used for audible devices such as bells and piezo mini-horns that may be silenced

either manually or automatically. While sounding, these devices follow the pattern appropriate for the condition: the configured Evacuation Code (default is Temporal Code) during alarm.

**Non-Silenceable Signal**

The Non-Silenceable Signal Circuit is used for audible devices such as bells and piezo mini-horns that may **not** be silenced either manually or automatically. While sounding, these devices follow the pattern appropriate for the condition: the configured Evacuation Code (default is Temporal Code) during alarm.

**Silenceable Strobe**

Silenceable strobes will be silenced when the “signal silence” key is pressed. For synchronous strobes see *supported protocol/devices* section. (NB: Strobes do not support any code pattern.)


**Non-Silenceable Strobes**

Non-Silenceable Strobes will not be silenced when the “signal silence” key is pressed. For synchronous strobes see *supported protocol/devices* section. (NB: Strobes do not support any code pattern.)

**Evacuation codes**

- Continuous      On 100% of the time
- Temporal Code    3 of 0.5 second on, 0.5 second off then, 1.5 second pause
- March Code      0.5 second on, 0.5 second off
- California Code   5 seconds on, 10 seconds off

**Figure 24: Evacuation Codes**



## Fire Alarm Operation

In a basic system set up all alarm inputs are treated in a similar manner. Alarm inputs include any of the following: Non-Verified Alarm, Verified Alarm, Sprinkler Alarm, and Water flow Alarm. If any of these alarm inputs occur when the panel is not already in alarm, the following occurs:

- The Buzzer sounds steadily
- If Fire Drill is active, it is cancelled
- The Common Alarm Indicator turns on
- The Auxiliary Common Alarm Relay activates if Aux Disconnect is not active
- The Auto Signal Silence Timer, if configured, starts
- The Signal Silence Inhibit Timer, if configured, starts
- All connected relays programmed to the input are activated (provided that Aux Disconnect is not active)
- Non-disconnected strobes associated with the input are activated
- Non-disconnected signals associated with the input are activated at the evacuation rate

Subsequent alarms when the panel is already in alarm cause the following:

- The alert buzzer sounds steadily
- If Signals have been silenced as a result of the Signal Silence button or the Auto Signal Silence Timer, Signals are resounded as they were before Signal Silence, the Signal Silence Indicator is turned off, and the Auto Signal Silence Timer, if configured, is restarted
- Any additional non-disconnected strobes associated with the new input are activated continuously
- Any additional non-disconnected signals associated with the new input are activated at the evacuation rate

## Supported Protocols/Devices

---

### Synchronous Strobes

The synchronous strobe models that are supported by the SFC-200 panel include Mircom models FHS-240 and FS-240. A separate compatibility list is available for different supported models.

Strobes can be configured as normal (e.g. not synchronized or any of the above; *see configuration section*). Any selection made is system-wide (e.g. whatever is selected applies to all the circuits in the system, configured as strobes).

#### “Signal silence” action on strobes

The “signal silence” action on strobes depends upon the configuration. The following describes the signal silence action on non-silenceable and silenceable strobes.

#### Non Silenceable strobe

If the output zone is configured as Non-Silenceable Strobe and if the “signal silence” is active on the panel while the strobes are active, the horn should be silenced. If the signal is active again the panel will activate the horn again.

#### Silenceable strobe

If the output circuit is configured as Silenceable Strobe, and if the “signal silence” is active on the panel, both the horn and strobe are completely turned off by turning off the output circuit. Re-activating the “signal silence” will turn them on again.



**Note:** Please see the strobes manufacturer’s data for details.

### System Sensor’s i<sup>3</sup> Devices

The SFC-200 fire control panel supports System Sensor’s i<sup>3</sup> devices. Only the two wire smoke detectors are supported on the i<sup>3</sup> zone, which are 2W-B and 2WT-B. Model 2WT-B features a built in fixed temperature (135F / 57.2C) thermal detector and is capable of sensing a freeze condition i.e. if the temperature is below 41F / 5 C.

The zones should be programmed to i<sup>3</sup> devices to be considered as i<sup>3</sup> zone (*see configuration section*). If the zone is not programmed as i<sup>3</sup> zone and i<sup>3</sup> devices are connected to the zone, it is simply treated as a regular zone. The panel is capable of detecting multiple troubles; if different devices have different troubles on the same zone, all troubles will be reported. The following troubles are reported for the i<sup>3</sup> devices.

#### i<sup>3</sup> zone Troubles

The following troubles can be reported for a zone configured as i<sup>3</sup> zone:

- Open circuit trouble
- Communication trouble
- Out of sensitivity: defective or dirty device
- Freeze trouble

### Open circuit trouble

If the loop is broken the panel shows open loop trouble. The panel can still communicate with the devices depending upon where the open occurs.

```
Zone-1
Open Trb.      1 / 1
```

### Communication Trouble

If there is a fault in the line or the line is too noisy, the panel cannot communicate with the devices. The panel shows a communication trouble in this case.

```
Zone-1
Communic. Trb  1 / 1
```

### Dirty Device trouble

If any of the devices on the i<sup>3</sup> zone are dirty, the panel shows a Dirty Device trouble. The device needs cleaning or be replaced with a new device.

```
Zone-1
Dirty Dev. Trb 1 / 1
```

### Out of sensitivity trouble

If any of the devices on the i<sup>3</sup> zone is out of sensitivity and cannot detect an alarm condition, the panel shows out of sensitivity trouble. In this condition the device is not usable and should be replaced.

```
Zone-1
Out of Sens Trb 1 / 1
```

### Freeze trouble

If the device has detected a freeze condition, (e.g. the temperature is below 41F / 5 C) then the panel will show a freeze trouble. Only model 2WT-B is capable of thermal detection; model 2W-B does not indicate any freeze trouble.

```
Zone-1
Freeze Trb.    1 / 1
```

The LEDs on the i<sup>3</sup> smoke detectors provide a local visual indication of the detector status.

i <sup>3</sup> Detector Condition	Green LED	Red LED
Power-up	Blinks every 10 sec	Blinks every 10 sec
Normal (Standby)	Blinks every 5 sec	OFF
Out of sensitivity (defective or dirty)	OFF	Blinks every 5 sec
Freeze trouble	OFF	Blinks every 10 sec
Alarm	OFF	Solid

# Configuration

There are three methods of configuring the SFC-200 LCD Series Fire Alarm Panels:

Direct configuration using the main LCD display and the menu buttons.


Using a PC or Lap Top Computer with a UIMA converter module.

Using a PC or laptop computer with remote connection (must use fire alarm with built-in UDACT).

The following information for configuring an SFC-200 LCD Series Fire Alarm Panel is based on using the front panel main LCD display for configuration.


**To access configuration mode press the Menu button on the front panel display.** The LCD will display the Main Menu. The function of different buttons on the front panel display is shown in *Figure 25*, below.

**Figure 25: SFC-200 Configuration**



## Entering the Passcode

The programming section is passcode protected. The following image shows the message that is displayed to enter the passcode. The minimum number of digits allowed is four and the maximum allowable passcode is ten digits long; numerical values only. Press the “ENTER” key after entering the passcode. If the passcode is right, it will take you to the main command menu. If the passcode is wrong the system will ask you to re-enter the passcode. The system will be exhausted after three retries and will then take you back to the Normal message display. The default password is “1111” (without quotes).



## Command Menu

The main command menu is pictured below. The first line of the LCD will always show “-Command Menu-“, and the second line scrolls through different selections. Use the “UP” and “DOWN” keys to scroll through the menu, and press the “ENTER” key to make a selection. To exit from the main command menu, select the “Exit” menu option and then press either the “CANCEL” or “ENTER” key.



**Note:** Command Menu features 1 and 9 can only be accessed if jumper JW5 is placed on the main board, see Table 1.

-Command Menu-
1. SFC-200 Config
2. Config Info
3. Set Time
4. Set Password
5. View EventLog
6. Clear EventLog
7. Walk Test
8. I3 Loop test
9. Dialer Config
10. Test Dialer
11. Bypass Det Ckt
12. Bypass NAC Ckt
13. Aux Disc
14. Exit

Pressing “LAMP TEST” at any time will show information about the system and the software version as shown below. It will also illuminate all the LEDs across the top of the display except for the CPU Fail LED.

FA-301-12DDR wUDACT
Version 0.0.4

The first line shows the model number and panel type and the second line shows the software version number. The version of the software is read as Major.Minor.Revision.

## 1. SFC-200 CONFIG (Command-Menu)

The following is a detailed description of the SFC-200 configuration menu.






-SFC-200 Config-
1. Features
2. Inp Zone
3. I3 Zone
4. Opt. Zone
5. Correlation
6. Inp Zone Label
7. Opt Zone Label
8. Default Config

### Command Menu/SFC-200 Config-->Features


- Feature Config -
1 Man. Sig. Sil.
2 Fire Drill
3 Opt. Ckt. Corr
4 Wtr/Sprk. Retd
5 Aux Dis Corr
6 Sig-Sil Inh Tmr
7 Aux Dis Alm&Sv
8 Auto Sil. Tmr
9 Rem. Annun.
10 Alm. Xmit-Sil.
11 Pwr Fail Tmr.
12 Com. Supv. Rly
13 Sig-Sil. Isol.
14 Strobe Type
15 Evac. Code
16 Active EOL

## How to Use the Keypad to Program the SFC-200

1. Press **MENU** to enter the command menu.
2. Select a Command Menu option by pressing **ENTER**. The corresponding submenu will display.
3. Use the up and down arrow buttons to scroll through the submenu.
4. Press **ENTER** to select a submenu option.
5. Use the left or right arrow buttons to select/unselect an option (selected = "X"). Use the up and down arrows to scroll through the different options.
6. Once you have made the correct selection, press **ENTER** to confirm the change. The display will return to the submenu screen.
7. Press **CANCEL** to return to the previous menu.

<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>1. Manual Signal Silence</b></p> 	<p>[X] ENABLE-&gt;Default  [ ] DISABLE</p>	<p>Use this function to enable or disable the SIGNAL SILENCE operation from the front panel.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>2.Fire Drill</b></p> 	<p>[X] ENABLE -&gt;Default  [ ] DISABLE</p>	<p>Use this function to enable or disable the FIRE DRILL operation.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>3.Output Circuit Correlation</b></p> 	<p>[X] DISABLE -&gt;Def  [ ] ENABLE</p>	<p>If disabled, whatever correlation is set in the correlation section is effective. If enabled, all the output circuits are correlated to all the input circuits.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>4.Waterflow/Sprinkler Retard Operation</b></p> 	<p>[X] DISABLE -&gt;Def  [ ] ENABLE</p>	<p>If disabled, all the initiating circuits configured as water flow or sprinkler act as non-verified alarms. If enabled, retard operation is performed for initiating circuits configured as water flow or sprinkler.  <i>(See Water flow Alarm and Sprinkler Alarm description)</i></p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>5.Aux. disconnect, disconnects Aux Alarm relay and all correlated relays</b></p> 	<p>[ ] ENABLE  [X] DISABLE-&gt;Default</p>	<p>In the default mode this function will disconnect the Auxiliary Alarm Relay when selected by Command Menu, Item 12 which acts like an Aux. disconnect switch.  If enabled, this function will disconnect the Auxiliary Alarm relay <u>and</u> all correlated relays when selected by Command Menu, Item 12 which acts like an Aux. disconnect switch.  <b>Correlated relays include: SRM212/SRM206 relays, SSR-212 relays.</b></p>

<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>6.Signal-Silence Inhibit timer</b></p> <pre>Sig-Sil. Inhibit Tmr [X] DISABLE</pre>	<p><input checked="" type="checkbox"/> DISABLE-&gt;Default  <input type="checkbox"/> 10 SEC  <input type="checkbox"/> 20 SEC  <input type="checkbox"/> 30 SEC  <input type="checkbox"/> 1 MIN</p>	<p>Use this function to inhibit the "SIGNAL SILENCE" switch for a desired length of time. This time period should expire before the signals may be silenced.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>7. Aux. disconnect, disconnects common alarm relay and common supervisory relay</b></p> <pre>Aux Dis,Dis Alm&amp;Spv [X] DISABLE</pre>	<p><input type="checkbox"/> ENABLE  <input checked="" type="checkbox"/> DISABLE-&gt;Default</p>	<p>If enabled, this function will disconnect (when selected by Command Menu, Item 12 which acts like an Aux. disconnect switch) the Common Alarm relay, the Common Supervisory relay and the SPR-200 will not transmit a supervisory or alarm event.</p> <p>If disabled, selecting Aux disconnect via the Command Menu, Item 12 (which acts like an Aux. disconnect switch) will have no effect on the Common Alarm relay, the Common Supervisory relay and the SPR-200.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>8.Auto Signal Silence Timer</b></p> <pre>Auto Sig-Sil. Timer [X] DISABLE</pre>	<p><input checked="" type="checkbox"/> DISABLE-&gt;Default  <input type="checkbox"/> 5 Min  <input type="checkbox"/> 10 Min  <input type="checkbox"/> 15 Min  <input type="checkbox"/> 20 Min  <input type="checkbox"/> 30 Min</p>	<p>Use this function to determine the time period for which the indicating circuits will sound before they are automatically silenced.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>9. Number of Remote Annunciators or smart relays</b></p> <pre>No. of Remote Annun. [X] NONE</pre>	<p><input checked="" type="checkbox"/> NONE-&gt;Default  <input type="checkbox"/> 1  <input type="checkbox"/> 2  <input type="checkbox"/> 3  <input type="checkbox"/> 4  <input type="checkbox"/> 5  <input type="checkbox"/> 6</p>	<p>Use this function to program the number of remote annunciators. Any combination of remote annunciators or smart relays can be used as long as the number does not exceed 6. The annunciators' addresses should be linear: without gaps and in sequence.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>10.Silence Alarm transmit</b></p> <pre>Alm. Xmit-Sil. [X] DISABLE</pre>	<p><input checked="" type="checkbox"/> DISABLE -&gt;Def  <input type="checkbox"/> ENABLE</p>	<p>Use this function to allow the alarm transmit and auxiliary alarm relay to reset on "SIGNAL SILENCE" rather than the "RESET" switch.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>11.AC power fail delay timer</b></p> <pre>AC Pwr Fail Dly Tmr. [X] NONE</pre>	<p><input checked="" type="checkbox"/> NONE -&gt;Default  <input type="checkbox"/> 8 HRS  <input type="checkbox"/> 18 HRS</p>	<p>Use this function to delay the AC power fail trouble for the programmed time period. If disabled, the AC power fail is reported right away.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>12.Common Supervisory Relay</b></p> <pre>Common Supv. Relay [X] ENABLE</pre>	<p><input checked="" type="checkbox"/> ENABLE -&gt;Default  <input type="checkbox"/> DISABLE</p>	<p>If disabled, the common supervisory relay can be used as common alarm relay. It will act the same way as a common alarm relay. If enabled, it is used a common supervisory relay.</p>

<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>13.Signal Isolators</b></p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>Sig-Sil. Isolator</p> <p><input checked="" type="checkbox"/> DISABLE</p> </div>	<p><input type="checkbox"/> ENABLE  <input checked="" type="checkbox"/> DISABLE -&gt;Def</p>	<p>Enable this function only when suite isolators are used (Canada only)</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>14.Strobe Type</b></p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>Strobe Type</p> <p><input checked="" type="checkbox"/> NORMAL</p> </div>	<p><input checked="" type="checkbox"/> NORMAL -&gt;Default  <input type="checkbox"/> MIRCOM  <input type="checkbox"/> FARADY  <input type="checkbox"/> WHEELLOCK  <input type="checkbox"/> GENTEX  <input type="checkbox"/> SYSTEM SENSOR</p>	<p>Use this function to select the manufacturer of the strobes used in the system. The selection is system-wide and applies to all indicating circuits configured as strobes. For "NORMAL" strobes there is no synchronization, while other strobes are synchronized and use manufacturer's protocol to synchronize the strobes.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>15.Evacuation Code</b></p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>Evacuation Code</p> <p><input checked="" type="checkbox"/> TEMPORAL</p> </div>	<p><input checked="" type="checkbox"/> TEMPORAL-&gt;Def  <input type="checkbox"/> CONTINOUS  <input type="checkbox"/> MARCH TIME  <input type="checkbox"/> CALIFORNIA</p>	<p>Use this function to set the rate at which the indicating circuits will sound.</p>
<p><b>Command Menu/SFC-200 Config/Features/</b>  <b>16. Active EOL</b></p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>Active EOL</p> <p><input checked="" type="checkbox"/> DISABLE</p> </div>	<p><input checked="" type="checkbox"/> DISABLE-&gt;Default  <input type="checkbox"/> ENABLE</p>	<p>Enable this function if using an Active EOL. If SICA-206 is used, this function should be enabled since the Class A Converter has built in Active EOL resistors.</p>
<p> <b>Note:</b> Refer to <i>How to Use the Keypad to Program the SFC-200</i> on page 40 for detailed instructions on making menu selections.</p>		

**Command Menu-->SFC-200 Config**



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

**Inp Zone**

```

Initiating Zone
1 Zone-1
2 Zone-2
--
--
12 Zone12
    
```

This menu is used to program the process type for the initiating circuits. The maximum number of initiating circuits supported is 12, but only those supported by the particular model will be shown.

<p><b>Command Menu/SFC-200 Config/pt. Zone</b></p> <p><b>1. Type (Initiating circuit)</b></p> <pre> Zone-1 Type [X] ALARM         </pre> <p><b>12.</b></p> <pre> Zone-12 Type [X] ALARM         </pre>	<pre> [X] ALARM -&gt;Default [ ] VERIF ALARM [ ] SPRKL ALM [ ] WTR-FLOW ALM [ ] NON-LATCH SUP [ ] LATCH SUPV [ ] GEN ALARM [ ] MONITOR [ ] TRB ONLY         </pre>	<p>Use this function to program the process type of each input zone. (See <i>CIRCUIT TYPE</i> section for details.)</p>
--	--	---

**Command Menu-->SFC-200 Config**

**i<sup>3</sup> Zone**

<pre> I3 Detection Zones [ ] Zone-1 [ ] Zone-2 -- -- [ ] Zone-12         </pre>	<pre> [ ] Zone-1-&gt;Default . . . [ ] Zone-12-&gt;Default         </pre>	<p>Use this function if i<sup>3</sup> devices are present on a zone. (See <i>i<sup>3</sup> devices</i> section for details).</p>
---	---	--

**Command Menu-->SFC-200 Config**



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

**Opt Zone**

Indicating Zone	
1	NAC-1
2	NAC-2
3	NAC-3
4	NAC-4

This menu is used to program the process type of the indicating circuits. The maximum number of indicating circuits is four, but only those supported by the particular model will be shown.

<p><b>Command Menu/SFC-200 Config/Opt. Zone</b></p> <p><b>1. Type (Indicating Circuits)</b></p> <div style="border: 1px solid gray; padding: 5px; margin-bottom: 10px;"> <p>NAC-1 Type</p> <p><input checked="" type="checkbox"/> SIL-ABLE</p> </div> <p>4.</p> <div style="border: 1px solid gray; padding: 5px;"> <p>NAC-4 Type</p> <p><input checked="" type="checkbox"/> SIL-ABLE</p> </div>	<p><input checked="" type="checkbox"/> SIL-ABLE-&gt;Default</p> <p><input type="checkbox"/> NON SIL-ABLE</p> <p><input type="checkbox"/> SIL-ABLE STR</p> <p><input type="checkbox"/> NON-SIL STR</p>	<p>Use this function to program the process type of each indicating circuit. See <i>CIRCUIT TYPE</i> section for details.</p>
--	---	---

**Command Menu-->SFC-200 Config**

**Correlation**

<p><b>Command Menu/SFC-200 Config/Correlation</b></p> <p><b>1. Correlation</b></p> <div style="border: 1px solid gray; padding: 5px; margin-bottom: 10px;"> <p>Zone-1 Corr.</p> <p><input checked="" type="checkbox"/> NAC-1</p> </div> <p>12.</p> <div style="border: 1px solid gray; padding: 5px;"> <p>Zone-12 Corr.</p> <p><input checked="" type="checkbox"/> NAC-1</p> </div>	<p><input checked="" type="checkbox"/> NAC-1 -&gt;Default</p> <p><input checked="" type="checkbox"/> NAC-2 -&gt;Default</p> <p><input checked="" type="checkbox"/> NAC-3 -&gt;Default</p> <p><input checked="" type="checkbox"/> NAC-4 -&gt;Default</p>	<p>Use this function to correlate initiating circuits to the indicating circuits. By default all the initiating circuits are correlated to all the indicating circuits.</p>
---	---	---

**Command Menu-->SFC-200 Config**



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

**Inp Zone Label**

```
Initiating Zone
1 Zone-1
2 Zone-2
--
--
12 Zone12
```

Use the keypad described below for entering a message.

**Command Menu/SFC-200 Config/lpt. Zone Label**

**1. Initiating zone label**

```
Zone-1 Label
Zone-1
```

**12.**

```
Zone-12 Label
Zone-12
```

```
[Zone-1 ]->Default
[Zone-12 ]->Default
```

KEYPAD TRANSLATION AS MARKED ON THE KEYS  
 Sequence refers to the number of times the key must be pressed to achieve the number or letter

```
KEY SEQ 1 2 3 4      KEY SEQ 1 2 3 4
```

```
-----
Key #1  1
Key #2  2 A B C      Key #3  3 D E F
Key #4  4 G H I      Key #5  5 J K L
Key #6  6 M N O      Key #7  7 P R S
Key #8  8 T U V      Key #9  9 W X Y
Key #0  0 Q Z        Key *  Backspace
Key #   Forward
```

Press the ENTER key to input the message.

**Command Menu-->SFC-200 Config**



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

**Opt Zone Label**

```

Indicating Zone
1 NAC-1
2 NAC-2
3 NAC-3
4 NAC-4
    
```

Use the keys in described below for entering a message. These letter keys are alternate functions of the numbered keys are physically located in the same position as described below.

<p><b>Command Menu/SFC-200 Config/Opt. Zone Label</b></p> <p><b>1.Indicating zone label</b></p> <div style="border: 1px solid gray; padding: 2px; margin: 5px 0;"> <pre>NAC-1 Label NAC-1</pre> </div> <p>4.</p> <div style="border: 1px solid gray; padding: 2px; margin: 5px 0;"> <pre>NAC-4 Label NAC-4</pre> </div>	<pre>[NAC-1      ]-&gt;Default [NAC-4      ]-&gt;Default</pre> <hr/> <p>KEYPAD TRANSLATION AS MARKED ON THE KEYS</p> <p>Sequence refers to the number of times the key must be pressed to achieve the number or letter</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: left;">KEY SEQ 1 2 3 4</td> <td style="text-align: left;">KEY SEQ 1 2 3 4</td> </tr> <tr> <td colspan="2" style="text-align: center;">-----</td> </tr> <tr> <td>Key #1 1</td> <td></td> </tr> <tr> <td>Key #2 2 A B C</td> <td>Key #3 3 D E F</td> </tr> <tr> <td>Key #4 4 G H I</td> <td>Key #5 5 J K L</td> </tr> <tr> <td>Key #6 6 M N O</td> <td>Key #7 7 P R S</td> </tr> <tr> <td>Key #8 8 T U V</td> <td>Key #9 9 W X Y</td> </tr> <tr> <td>Key #0 0 Q Z</td> <td>Key * Backspace</td> </tr> <tr> <td>Key # Forward</td> <td></td> </tr> </table> <p>Press the ENTER key to input the message.</p>	KEY SEQ 1 2 3 4	KEY SEQ 1 2 3 4	-----		Key #1 1		Key #2 2 A B C	Key #3 3 D E F	Key #4 4 G H I	Key #5 5 J K L	Key #6 6 M N O	Key #7 7 P R S	Key #8 8 T U V	Key #9 9 W X Y	Key #0 0 Q Z	Key * Backspace	Key # Forward	
KEY SEQ 1 2 3 4	KEY SEQ 1 2 3 4																		
-----																			
Key #1 1																			
Key #2 2 A B C	Key #3 3 D E F																		
Key #4 4 G H I	Key #5 5 J K L																		
Key #6 6 M N O	Key #7 7 P R S																		
Key #8 8 T U V	Key #9 9 W X Y																		
Key #0 0 Q Z	Key * Backspace																		
Key # Forward																			

**Command Menu-->SFC-200 Config**

**Default Configuration**

<div style="border: 1px solid gray; padding: 2px; margin: 5px 0;"> <pre>Load the default settings? Y</pre> </div> <p>Press "UP" and "DOWN" to select between Y/N. if "ENTER" is pressed the default configuration is restored.</p> <div style="border: 1px solid gray; padding: 2px; margin: 5px 0;"> <pre>Default settings have been loaded</pre> </div>	<p>Use this function to load the default configuration in the panel.</p> <p><b>Warning:</b> By loading default configuration all the previously programmed configuration is lost permanently.</p>
---	---


## 2. Config Info (Command-Menu)







**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

<p>Configuration type: Factory default</p> <p>Press down arrow key to see more information.</p>	<p>Configuration type will show how the panel was configured. "Factory default" means the panel has not been configured, it is as it came from the factory. "Front Panel" means it was configured at the panel. "Serial Port" means the configuration was done from a computer through the serial port. "Modem" means the configuration was completed remotely through a modem.</p>
<p>Job Name: No job loaded</p>	<p>If you upload a job configuration to the panel using the PC configuration utility, the job name will appear on this screen. The job name can be up to a maximum of 20 characters.</p>
<p>Technician ID: Unknown</p> <p>Press down arrow key for further info</p>	<p>If you upload a job configuration to the panel using the PC configuration utility, the technician's name (ID) will appear on this screen. The technician ID can be up to a maximum of 10 characters.</p>
<p>Cfg. Date and Time: hh:mm day year:mm:dd</p> <p>Press down arrow key for further info</p>	<p>Configuration date and time will appear for all means of configuration, thus revealing date and time configuration was last changed.</p>
<p>Cfg. Tool S/W Vers.: Version:x.x.x.x</p>	<p>This specifies the configuration tool version. It will display 0.0.0.0 if no PC configurator has been used.</p>

### 3. Set Time (Command-Menu)



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

<p><b>Command Menu/Set Time</b> 1. Daylight saving time</p> 	<p>[X] DISABLE -&gt;Default [ ] ENABLE</p>	<p>Use this function to enable daylight savings time.</p>
<p><b>Command Menu/Time Clock</b> 2. Set time and date</p> 	<p>Default 00:00 MON 2000-01-01</p>	<p>Use this function to set the time and date. Use the "LEFT" and "RIGHT" keys to move the cursor to the desired location in the display and use the "UP" and "DOWN" keys to increase or decrease the values. Press the "ENTER" key to accept the changes and the "CANCEL" key to ignore the changes. <b>Note:</b> time is in 24hr format</p>
<p><b>Command Menu/Time Clock</b> 3. Compensation</p>  <p><b>Once the compensation value is entered the display will be:</b></p> 	<p>Compensation value can range from -15 to +15 seconds.</p>	<p>Use the up down arrow keys to select daily compensation value and press ENTER. For a fast clock adjust negatively. For a slow clock adjust positively. For example: for a clock which runs 5 minutes a month (based on 30 days) fast select -10 seconds.</p>

## 4. Set Password (Command-Menu)




**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

<p>Enter new passcode [    ]</p> <p>Re-enter passcode [    ]</p> <p>If the passcode does not match, the following message appears and the system exit to the main menu</p> <p>invalid passcode</p> <p>If the passcode is OK the following message appears and exits to the main menu</p> <p>Passcode updated</p>	<p>1111 -&gt; Default</p>	<p>Use this function to change the passcode. The minimum number of digits is 4 and the maximum number is 10. ONLY numeric digits are allowed.</p>
--	---------------------------	---

## 5. View Event Log (Command-Menu)

The event log looks the same as the normal event queue. Pressing the “INFO” key has the same effect that it does in the event queue. The illustration below provides an example of how the “INFO” key works.



There are a maximum of 200 recent events saved in the event log. If the number of events goes beyond 200, the oldest event is overwritten by the most recent one.

## 6. Clear Event Log (Command-Menu)



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

```
-Select Log-
```

```
1 Alarm Log
```

```
2 General Log
```

```
3 All Logs
```

Select the type of log to clear. Press the "ENTER" key. The system will then confirm before clearing logs.

```
Clear all the  
selected log(s)? Y
```

Press the "ENTER" key to confirm or the "CANCEL" key to cancel the operation.

```
Log(s) cleared
```

Use this function to clear alarm logs, general logs, or both.

## 7. Walk Test (Command-Menu)



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

Walk-Test allows an installer to verify the initiating circuit wiring in a system. When walk test is selected, the following screen confirms the operation:

```
Perform the
walk test? Y
```

Press the “ENTER” key to activate the walk test and the “CANCEL” key to cancel the walk test. The next screen will allow zones to be selected for walk test. Use the “UP” and “DOWN” keys to scroll through the zones and use the “LEFT” or “RIGHT” keys to select a zone. Press the “ENTER” key when you are done with all the selections.

```
-WALK TEST ZONES-
[ ] Zone-1
```

The walk test is now active (*see illustration below*)

```
-Walk test active-
Alarm:00      Trb:00
```

The activation of any initiating circuit that has been selected for a walk test will cause the Audible Indicating Circuits (not Strobes) to activate briefly for a number of short bursts corresponding to the selected circuit number. If the first selected circuit is activated, the indication circuits will sound for one burst. If the second selected circuit is activated, the indication circuits will sound for two bursts, and so on. This means that if, for example, circuits 1, 3 and 5 were selected for the walk test, the indicating circuits would sound with one, two and three bursts respectively. The burst interval is half a second ON and half a second OFF. After the sounding pattern has been sent to the indicating circuits, the initiating circuit is reset and tested again. If it is still active (in alarm) the pattern will be re-sent. Trouble on any initiating circuit selected for the walk test activates the indicating circuits continuously for five seconds. Activation of a circuit will also cause the alarm count to increase while the trouble on the initiating circuit will cause the trouble count to increase.

Alarm Verification and Water flow Alarm Retard Operations are disabled on circuits being walk tested. All circuits not selected for the walk test continue to function normally. If a circuit was disconnected before the walk-test mode was entered and is not selected for the walk-test, it remains disconnected while the walk test is active. Walk test operation is disabled if the Fire Alarm Control Panel is in alarm or goes into alarm while the walk test is active.



**Notes:**

- If a UDACT is used with the system, all walk-test events will be reported to the monitoring agency. The monitoring agency should be instructed to ignore reported events during the walk-test.
- IF THERE IS NO ACTIVITY FOR ONE HOUR, THE SYSTEM WILL RETURN TO NORMAL OPERATION.

## 8. i<sup>3</sup> Loop Test (Command-Menu)



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

The i<sup>3</sup> maintenance test is designed to test the devices on the i<sup>3</sup> zone. If there is noise on the line or if the device is too far away from the panel, the devices may not respond to the panel inquiries. An i<sup>3</sup> maintenance test can be invoked from the command menu. If the fire alarm has just been powered up or reset, wait six minutes before selecting the i<sup>3</sup> loop test. If the i<sup>3</sup> loop test is selected, the following message appears on the screen:

```
Perform the i3
Loop test? Y
```

If you select “yes” by pressing “ENTER”, the display will ask you for which zone you want to perform the i<sup>3</sup> test. Note that only one zone at a time can be in maintenance test. Select the zone by pressing the “UP” and “DOWN” keys and then pressing the “RIGHT” key to select the device. After the device is selected press “ENTER”.

```
- I3 TEST ZONES -
[ ] Zone-1
```

If the i<sup>3</sup> maintenance test is selected within six minutes after power-up or reset, the following information message is displayed.

```
The selected zone
is not ready yet
```

If a zone is selected that is not configured as an i<sup>3</sup> zone, the following message is displayed:

```
The selected zone
is not i3 type
```

Once the zone goes into the i<sup>3</sup> loop test, no other zone can be put into the test. The maintenance test will take five minutes. During this time you can walk through the device and make sure all the devices are working properly. The following table lists the status of the devices while in loop test.



**Note:** Out of sensitivity can mean the device is dirty.

i <sup>3</sup> Detector Condition	Green LED	Red LED
Proper operation	Double blink every 5 sec	OFF
Out of sensitivity	OFF	Double blink every 5 sec
Freeze condition	OFF	Double blink every 10 sec

You can cancel the maintenance test either by pressing the “RESET” key or by going into the configuration section and canceling the test.

## 9. Dialer Config (Command-Menu)



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

The following illustration shows the dialer configuration menu. Each item in this menu is described below in detail.

```
-Dialer Config-
1 Account Info
2 Telephone line
3 Report Options
4 Time Parameter
5 Enable/Disable
6 Ring Detect
```

### Command Menu-->Dialer Config

#### Account Info

```
- Account Info -
1 Account#1 ID
2 Account#1 Tel
3 Acct#1 Format
4 Account#2 ID
5 Account#2 Tel
6 Acct#2 Format
```

#### Command Menu/Dialer Config/Account Info

#### 1.Account# 1 Identification


```
Account#1 ID:
_
```

123456->Default

Use this function to set the Account ID for the monitoring station to which the dialer reports events. The maximum # of digits allowed is six. For contact ID, only the first four digits are used; the last two are truncated.

Unless you are using the SIA protocol, the allowed digits for the account ID are simple digits 0 to 9 and hexadecimal digits A to F (the SIA protocol only allows digits 0 to 9).

To enter hexadecimal digits, press the INFO button. The letter "A" will appear. To scroll through the rest of the letters, press INFO repeatedly. Press # to move the cursor to the right or press \* to move it to the left.

<p><b>Command Menu/Dialer Config/Account Info</b></p> <p><b>2.Account#1 Telephone Number</b></p> <div style="border: 1px solid gray; padding: 5px; width: fit-content;"> <p>Account#1 Telnum:</p> <p>—</p> </div>	<p>[ 101 ]-&gt;Default</p>	<p>Use this function to set the telephone number of the monitoring station. The maximum # of digits allowed is 19 including “,” and numerals. The “,” will be treated as 1 sec delay. To enter “,” press the INFO button. Press # to move the cursor to the right or press * to move it to the left. An example of a typical telephone # is 9,,12345678.</p>
<p><b>Command Menu/Dialer Config/Account Info</b></p> <p><b>3.Account#1 Reporting Format</b></p> <div style="border: 1px solid gray; padding: 5px; width: fit-content;"> <p>ACCNT#1 Format:</p> <p>[X] Contact ID</p> </div>	<p>[X] CONTACT ID-Def [ ] SIA 300 Baud [ ] SIA 110 Baud</p>	<p>Set the reporting format that is recognized or preferred by the monitoring station.</p>
<p><b>Command Menu/Dialer Config/Account Info</b></p> <p><b>4. Account# 2 Identification</b></p> <div style="border: 1px solid gray; padding: 5px; width: fit-content;"> <p>Account#2 ID:</p> <p>—</p> </div>	<p>654321-&gt;Default</p>	<p>Same as Account#1.</p>
<p><b>Command Menu/Dialer Config/Account Info</b></p> <p><b>5.Account# 2 Telephone Number</b></p> <div style="border: 1px solid gray; padding: 5px; width: fit-content;"> <p>Account#2 Telnum:</p> <p>—</p> </div>	<p>[ 101 ]-&gt;Default</p>	<p>Same as Account#1.</p>
<p><b>Command Menu/Dialer Config/Account Info</b></p> <p><b>6.Account# 2 Reporting Format</b></p> <div style="border: 1px solid gray; padding: 5px; width: fit-content;"> <p>ACCNT#2 Format:</p> <p>[X] Contact ID</p> </div>	<p>[X] Contact ID-Def [ ] SIA 300 Baud [ ] SIA 110 Baud</p>	<p>Same as Account#1.</p>
<p> <b>Note:</b> Refer to <i>How to Use the Keypad to Program the SFC-200</i> on page 40 for detailed instructions on making menu selections.</p>		

**Command Menu-->Dialer Config**



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

**Telephone Line**

```
- Telephone Line -
1 Line1 Dialtype
2 Line2 Dialtype
3 Line1 Dialtone
4 Line2 Dialtone
5 Num of Retries
```

<p><b>Command Menu/Dialer-Config/Telephone Line</b></p> <p><b>1. Line#1 Dialing Type</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>Line#1 Dialing Type:</p> <p><input checked="" type="checkbox"/> DTMF Dial</p> </div>	<p><input checked="" type="checkbox"/> DTMF Dial-&gt;Def  <input type="checkbox"/> Pulse Dial</p>	<p>Set the dialing type for line #1; this is the type recognized or preferred by the telephone company.</p>
<p><b>Command Menu/Dialer-Config/Telephone Line</b></p> <p><b>2. Line#2 Dialing Type</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>Line#2 Dialing Type:</p> <p><input checked="" type="checkbox"/> DTMF Dial</p> </div>	<p><input checked="" type="checkbox"/> DTMF Dial-&gt;Def  <input type="checkbox"/> Pulse Dial</p>	<p>Same as Line#1.</p>
<p><b>Command Menu/Dialer-Config/Telephone Line</b></p> <p><b>3. Line#1 wait for Dial tone</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>Line#1 Wait Dialtone</p> <p><input checked="" type="checkbox"/> ENABLE</p> </div>	<p><input checked="" type="checkbox"/> ENABLE -&gt;Default  <input type="checkbox"/> DISABLE</p>	<p>Use this function to let the system know whether or not to wait for a dial tone before dialing. Cell phone setup for the dialer requires that the system not wait for dial tone before dialing.</p>
<p><b>Command Menu/Dialer-Config/Telephone Line</b></p> <p><b>4.Line#2 wait for Dial tone</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>Line#2 Wait Dialtone</p> <p><input checked="" type="checkbox"/> ENABLE</p> </div>	<p><input checked="" type="checkbox"/> ENABLE -&gt;Default  <input type="checkbox"/> DISABLE</p>	<p>Same as Line#1.</p>
<p><b>Command Menu/Dialer-Config/Telephone Line</b></p> <p><b>5.Number of retries</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>Number of Retries:</p> <p>06</p> </div>	<p>06 -&gt;Default</p>	<p>Set the number of retries for both line#1 and line#2. This function lets the dialer retry on either line if it is busy or not available. If the retry count expires, the panel reports a line trouble.</p>

**Command Menu-->Dialer-Config**



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

**Report Options**

```
- Report Options -
1 Alarm Prio.
2 Trouble Prio.
3 Supv. Priority
4 Aux Dis Report
5 Fire Panel
6 Operation Mode
7 Checksum Bits
```

<p><b>Command Menu/Dialer-Config/Report Options</b> <b>1.Alarm priority</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>Alarm Priority: [X] Account 1</p> </div>	<p>[X] Account 1-&gt;Def [ ] Account 2</p>	<p>Use this function to set the account priority for reporting alarms. If the priority is set for account#1 then the dialer will try account#1 first for reporting.</p>
<p><b>Command Menu/Dialer-Config/Report Options</b> <b>2.Trouble priority</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>Trouble Priority: [X] Account 1</p> </div>	<p>[X] Account 1-&gt;Def [ ] Account 2</p>	<p>Use this function to set the account priority for reporting trouble. If the priority is set for account#1 then the dialer will try account#1 first for reporting.</p>
<p><b>Command Menu/Dialer-Config/Report Options</b> <b>3.Supervisory priority</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>SUPV Priority [X] Account 1</p> </div>	<p>[X] Account 1-&gt;Def [ ] Account 2</p>	<p>Use this function to set the account priority for reporting supervisory troubles. If the priority is set for account#1 then the dialer will try account#1 first for reporting.</p>
<p><b>Command Menu/Dialer-Config/Report Options</b> <b>4.Aux Disconnect, Cancels Alarm &amp; Supv Reporting Thru dialer</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>AuxDis Alm&amp;Supv Rpt. [X] DISABLE</p> </div>	<p>[ ] ENABLE [X] DISABLE -&gt;Default</p>	<p>If this function is enabled, the AUX DISCONNECT feature (Command Menu, Item 12 as a switch) will block the alarm and supervisory events from the being reported through the built-in dialer.</p>
<p><b>Command Menu/Dialer-Config/Report Options</b> <b>5.Fire Panel type</b></p> <div style="border: 1px solid gray; padding: 2px;"> <p>Fire Panel Type: [X] SFC-200 Panel</p> </div>	<p>[X] SFC-200 Panel-&gt;Def [ ] FA-1000 Panel [ ] FX-2000 Panel</p>	<p>Do not change this function; keep it as default. <b>For factory use only.</b></p>

<p><b>Command Menu/Dialer-Config/Report Options</b>  <b>6.Dialer operation mode</b></p> <pre>Dialer Oper. Mode: [X] (U) DACT</pre>	<pre>[X] (U) DACT -&gt;Default [ ] DACT</pre>	<p>Use this function to select the functionality of the dialer. In DACT mode only common trouble/alarm/supervisory are reported while in UDACT mode all point information is reported</p>
<p><b>Command Menu/Dialer-Config/Report Options</b>  <b>7.Checksum Bits</b></p> <pre>Checksum Bits: [X] 8 Bits</pre>	<pre>[X] 8 Bit -&gt;Default [ ] 16 Bits</pre>	<p>Do not change this function; keep it as default  <b>For factory use only.</b></p>

**Command Menu-->Dialer-Config**



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

**Time Parameters**

```
-Time Parameter-
1 AC-Loss Delay
2 Cellphone Date
3 Auto-Test Time
```

<p><b>Command Menu/Dialer-Config/Time Parameter</b>  <b>1.AC Loss delay</b></p> <pre>AC-Loss Delay(Hrs) 0</pre>	<pre>0 -&gt;Default 0 to 20 hours</pre>	<p>Use this function to delay the reporting of AC loss trouble on the dialer for the programmed time period.</p>
<p><b>Command Menu/Dialer-Config/Time Parameter</b>  <b>2.Cellular report date</b></p> <pre>Cellular Report Date 0</pre>	<pre>0 -&gt;Default</pre>	<p>Use this function to set the test report date for the cell phone setup. If the date is set to 0, there will be no test reporting for cell phone or regular telephone line. Other settings could be anywhere from 01-28, representing which day of the month the test should be performed. When a cell phone service is employed for the panel, it should only be connected to telephone line #2 CO interface. Also, the dial tone detection feature of Line #2 should be disabled for cell phone application.</p>
<p><b>Command Menu/Dialer-Config/Time Parameter</b>  <b>3.Auto test time</b></p> <pre>Auto-Test Time 00:30</pre>	<pre>00:30 -&gt;Default</pre>	<p>Use this function to set the time for auto test. This test has to be performed once a day to send the test report to the monitoring station. The time is in 24hr format, which means 00:30 is 30 minutes after midnight.  <b>Please avoid the following Test Times: 00:00, 01:55, 02:00 and 03:00</b></p>

**Command Menu-->Dialer-Config**



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

**Dialer Enable/Disable**

<pre>Dialer Ena/Dis [X] ENABLE</pre>	<pre>[X] ENABLE -&gt;Default</pre>	<p>The dialer is enabled by default. When the dialer is enabled or disabled, a warning message appears.</p> <p><b>Warning:</b> The dialer cannot report any event to the monitoring station if it is disabled.</p>
<pre>-----Warning----- Dialer Disabled!!!</pre>	<pre>[ ] DISABLE</pre>	

**Command Menu-->Dialer-Config**

**Ring Detect**

<pre>-Ring Detect Number- [X] 5</pre>	<pre>[ ] Disabled [ ] 1 [ ] 2 [ ] 3 [ ] 4 [X] 5-&gt;Default [ ] 6 [ ] 7 [ ] 8</pre>	<p>Use this menu item to select the number of rings on which the panel's modem will answer. The default number of rings is five. The maximum number of rings you can define is eight.</p> <p>If you select the "Disabled" option, the modem will be disabled and the panel will not pick up the incoming call.</p>
---------------------------------------	---	--

**10. Test Dialer (Command-Menu)**

<pre>-Dialer Test- 1. L#1 Manual test 2. L#2 Manual test 3. Reset Dialer</pre>
--



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

<pre>1.L#1 Manual test</pre>	<p>Press Enter to test Line #1. Press Cancel to exit this menu. For a description of test messages, see <i>Dialer Test Messages</i> on the following page.</p>
<pre>2.L#2 Manual test</pre>	<p>Press Enter to test Line #2. Press Cancel to exit this menu. For a description of test messages, see <i>Dialer Test Messages</i> on the following page.</p>
<pre>3.Reset Dialer</pre>	<p>This feature flushes all reportable events from the buffer. Press Enter to reset the dialer. Press Cancel to exit this menu.</p>

## Dialer Test Messages

The following messages will display during the test processes of Lines #1 and #2. The messages that will appear depend on the status of the dialer and the test results that are found.

Dialer idle now	The dialer is checking the line for voltage. This message automatically displays when Manual Test is selected.
No DC Volt	No DC line voltage. The line is dead or no phone line is connected.
Waiting for Dialtone	The dialer is waiting for a dial tone.
Failed: No Dialtone	This message may indicate a noisy telephone line.
Dialing Receiver Now	The dial tone was received and telephone number dialing is in process.
No DTMF tone	This message indicates that the dialer failed to send a DTMF tone.
Waiting for Acktone	Waiting for availability of the receiver. The receiver confirms the availability by sending an ack tone.
Failed No Acktone	This message indicates that either the telephone number may be wrong or the receiver is not available.
Reporting Event Now	When sending events to the receiver, the display will toggle between this message and "Waiting for Kissoff " for all events sent.
Waiting for Kissoff	The dialer is waiting for the kissoff tone. The kissoff tone indicates that the receiver has received the event reports.
No Kissoff	No Kissoff means receiver has not received any event reports.
Passed: Manual test	The line passed the test; everything is OK.

## 11. Bypass Det Ckt (Command-Menu)



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

<pre>Bypass Det Zone 1.Zone-1</pre>	<p>Initiating zones may be bypassed individually. This bypass command will allow you to scroll through all initiating zones 1 to a maximum of 12 depending on the size of the panel.</p>
<pre>[ ]Bypassed</pre>	<p>Press Enter to bypass the zone or scroll up or down to un-bypassed (normal connected circuit).</p>
<pre>[ ]Un-Bypassed</pre>	<p>Press Enter to un-bypass the zone or scroll up or down to bypass (off normal unconnected circuit).</p>

## 12. Bypass NAC Ckt (Command-Menu)

<pre>Bypass Det Zone 1.Zone-1</pre>	<p>Indicating zones may be bypassed individually. This bypass command will allow you to scroll through all indicating zones 1 to a maximum of 4 depending on the size of the panel.</p>
<pre>[ ]Bypassed</pre>	<p>Press Enter to bypass the zone or scroll up or down to un-bypassed (normal connected circuit).</p>
<pre>[ ]Un-Bypassed</pre>	<p>Press Enter to un-bypass the zone or scroll up or down to bypass (off normal unconnected circuit).</p>

## 13. Aux. Disconnect (Command-Menu)

<pre>Disconnect Aux Relay?[Y]</pre>	<p>Use the up or down keys to change from YES to NO. This selection work like a switch. If Yes this command disconnects the auxiliary alarm relay and associated relays as long as the Aux disc feature has been enabled.</p>
-------------------------------------	---

## 14. Exit (Command-Menu)



**Note:** Refer to *How to Use the Keypad to Program the SFC-200* on page 40 for detailed instructions on making menu selections.

Pressing “ENTER” after selecting “Exit” from the main menu will return the panel to normal LCD operation.


### Zone messages

Point annunciation is indicated on the LCD display. There are no separate queues for “TROUBLE”, “ALARM”, “SUPERVISORY” and “MONITOR”; instead there is only one queue that indicates all the events. The respective TROUBLE, ALARM and SUPVISORY LEDs will be flashing if at least one of the given types is in the queue.

Scroll through the events by using the “UP” and “DOWN” keys. If you need more information about the displayed event, press the “INFO” key.


### Example 1 (detection circuit):

Event “01/09” 01 of 09, “OPEN TRB” on physical “Z-01” at “EAST LOBBY ENTRANCE” with process type as “VERIFIED ALARM” and the event occurred on “2003/04/04” at “18:01 TUESDAY”.



### Example 2 (indicating circuit):

Event “02/09” 02 of 09, “SHORT TRB” on physical “NAC-01” at “EAST WING LOBBY” with process type as “SILENCEABLE” and the event occurred on “2003/02/02” at “18:01 TUESDAY”.




**Note:** The queue hierarchy is Alarm, Supervisory, Trouble and Monitor ie, alarm has the highest priority and will always be shown at the beginning of the queue, followed by supervisory alarms, troubles and monitor zone troubles.

Other common messages are listed on the following pages.


**AC Power Fail**

The AC power fail trouble is generated when the power drops below the UL specified value. The trouble is restored when the power returns to the normal value.




**Battery trouble**

The battery trouble is generated when the battery voltage drops below the specified UL value. The trouble is restored when the voltage returns to the normal value.




**Ground Fault**

The "Ground Fault" message indicates that there is a short in the electrical connection between the metal chassis of the panel and the earth.




### Remote Annunciator

Troubles related to the annunciator can have two possibilities: either the main panel and annunciator failed to communicate with each other, or an unconfigured remote annunciator is responding to the main panel. In both the cases, the following trouble message is displayed:



### Four-wire smoke detector supply


The four-wire smoke detector supply is supervised for shorts. When a short is detected on the four-wire smoke supply the power is cut off and a trouble message is generated. Press the system "RESET" key to restore power to the system. If the short is removed, the panel will return to normal; otherwise the trouble message will stay.



### Supervised auxiliary supply

The supervised auxiliary supply is supervised for shorts. When a short is detected on supervised aux supply the power is cut off and a trouble message is generated. Press the system "RESET" key to restore power to the system. If the short is removed, the panel will return to normal; otherwise the trouble message will stay.


**Note:** The trouble code and info is for trained service personnel only.




### City tie Polarity reversal - SPR-200/ Relay module

The city tie or polarity reversal module is supervised for open and whether or not the SPR-200 is plugged in. The relay module is supervised for whether or not it is plugged in.

If any of the modules are not plugged in, the following trouble message is generated:



If there is an open detected on the city tie output, the following trouble message is displayed:



**Note:** The trouble code and info is for trained service personnel only.

## Appendix A: Compatible Receivers

---

The dialers that are built into select models of the SFC-200 Series Fire Alarm Control Panels are compatible with the following Digital Alarm Communicator Receivers (DACR):

### DACR Receiver Model

SurGard MLR2 Multi-Line Receiver (ULC, ULI approved)  
 SurGard SLR Single-Line Receiver (ULC, ULI approved)  
 Osborne-Hoffman Quickalert! II Receiver (ULI approved)  
 Osborne-Hoffman OH-2000 Receiver (ULI Approved)  
 Silent Knight Model 9500 Receiver (ULI Approved)  
 Radionics Model D6500 Receiver (ULI Approved)  
 Radionics Model D6600 Receiver (ULI Approved)

### Protocols

SIA-DCS and Ademco Contact ID  
 SIA-DCS and Ademco Contact ID  
 SIA-DCS and Ademco Contact ID  
 SIA-DCS and Ademco Contact ID  
 SIA-DCS and Ademco Contact ID  
 SIA-DCS and Ademco Contact ID  
 SIA-DCS and Ademco Contact ID

## Appendix B: Reporting

### Ademco Contact-ID

#### SFC-200 Event Codes

Event Description	Event Family	Qualifier	Code	Group #	Contact #
Phone Line #1 trouble detected	Trouble	New event	1 351	00	000
Phone Line #2 trouble detected	Trouble	New event	1 352	00	000
Phone Line #1 trouble restored	Trouble	Restore	3 351	00	000
Phone Line #2 trouble restored	Trouble	Restore	3 352	00	000
Failure to report to an Account	Trouble	New event	1 354	Acct #	Acct #
Report to an Account successful	Trouble	Restore	3 354	Acct #	Acct #
RS-485 Communication Trouble	Trouble	New event	1 350	00	485
Periodic (24 hr) Test Event (NORMAL)	Test	New event	1 602	00	000
Periodic (24 hr) Test Event (OFF NORMAL)	Test	New event	1 608	00	000
Manually initiated dialer test	Test	New event	1 601	00	000
Zone Fire Alarm	Alarm	New event	1 110	00	NNN
Zone Fire Alarm restored	Alarm	Restore	3 110	00	NNN
Zone Trouble detected	Trouble	New event	1 300	00	NNN
Zone Trouble restored	Trouble	Restore	3 300	00	NNN
Zone Supervisory condition	Supervisory	New event	1 200	00	NNN
Zone Supervisory restored	Supervisory	Restore	3 200	00	NNN
Waterflow	Alarm	New event	1 113	00	NNN
Waterflow restored	Alarm	Restore	3 113	00	NNN
Indicating Zone Trouble	Trouble	New event	1 320	00	NNN
Indicating Zone Trouble restored	Trouble	Restore	3 320	00	NNN
General Alarm	Alarm	New event	1 140	00	NNN
General Alarm restored	Alarm	Restore	3 140	00	NNN
AC power lost	Trouble	New event	1 301	00	000
AC power restored	Trouble	Restore	3 301	00	000
Battery Low	Trouble	New event	1 302	00	000
Battery Low restored	Trouble	Restore	3 302	00	000
Ground Fault	Trouble	New event	1 310	00	000
Ground Fault restored	Trouble	Restore	3 310	00	000

**NNN**-Refers to Sensor number for zone causing event.

## Security Industries Association SIA-DCS

SIA protocol does not define indicating zone troubles, but lists it as Untyped Zone Trouble/Restore.

### SFC-200 Event Codes

Event Description	Event Family	Qualifier	SIA Event Code	Parameter
Phone Line #1 trouble detected	Trouble	New event	LT	001
Phone Line #2 trouble detected	Trouble	New event	LT	002
Phone Line #1 trouble restored	Trouble	Restore	LR	001
Phone Line #2 trouble restored	Trouble	Restore	LR	002
Failure to report to an Account	Trouble	New event	RT	Acct #
Report to an Account successful	Trouble	Restore	YK	Acct #
RS485 Communication Trouble	Trouble	New event	YS	485
Periodic (24 hr) Test Event (Normal)	Test	New event	RP	000
Periodic (24 hr) Test Event (Off-normal)	Test	New event	RY	000
Manually initiated dialer test	Test	New event	RX	000
Zone Fire Alarm	Alarm	New event	FA	NNN
Zone Fire Alarm restored	Alarm	Restore	FH	NNN
Zone Trouble detected	Trouble	New event	FT	NNN
Zone Trouble restored	Trouble	Restore	FJ	NNN
Zone Supervisory condition	Supervisory	New event	FS	NNN
Zone Supervisory restored	Supervisory	Restore	FR	NNN
Waterflow alarm	Alarm	New event	WA	NNN
Waterflow alarm restored	Alarm	Restore	WH	NNN
General Alarm	Alarm	New event	QA	NNN
General Alarm restored	Alarm	Restore	QH	NNN
Indicating Zone Trouble (*)	Trouble	New event	UT	NNN
Indicating Zone Trouble restored (*)	Trouble	Restore	UR	NNN
AC power lost	Trouble	New event	AT	000
AC power restored	Trouble	Restore	AR	000
Battery Low	Trouble	New event	YT	000
Battery Low restored	Trouble	Restore	YR	000
Ground Fault	Trouble	New event	YP	000
Ground Fault restored	Trouble	Restore	YQ	000

## Appendix C: Specifications

### SFC-200 Fire Alarm Control Panel (LCD)

Digital Signal Processor (DSP) based design. Fully configurable using front panel LCD display with Password Access.

#### Electrical Ratings

##### AC line voltage

120 VAC 50 Hz 3 amps\ 240 VAC, 50 Hz, 1.5A (primary)

##### Power Supply Rating

6 amps maximum (secondary)

##### Battery

Type: 24VDC Gel-Cell/Sealed lead acid

Charging capability: 10AH

Protection: 10A on board (F1) slow blow micro fuse

#### Indicating circuit

4 supervised style Z (Class B) indicating circuits, configured as normal or visual. Terminals are labeled "SIG".

Power limited / 24VDC unfiltered / 1.7A @ 49C per circuit

Max power allowed = 5A

- 1.7A (aux power unfiltered if used)
- 0.5A (aux power filtered if used)
- 0.3A (4-wire smoke power if used)

if no auxiliaries are used the max power is 5A

**Current consumption** Standby 283mA/Alarm 560mA

#### Aux supply (non resettable)

power limited / 22.3VDC regulated / 500mA max

#### 4-wire smoke supply (resettable)

Power limited/22.3Vdcregulated / 300mA max

#### Unfiltered supply (full wave rectified)

Power limited / 24VDC unfiltered / 1.7A max at 49C

#### Auxiliary Relays (Common alarm/supv/trb/ and auxiliary second alarm)

Must be connected to a listed power-limited source of supply

FormC / 28VDC / 1A max

#### Initiating circuit

12 supervised style B (Class B) initiating circuits, configurable (normal or verified). Terminals are labeled "DET". Compatibility ID "A"

Power limited / 19VDC reg. / 3mA for detectors / 0.15Vp-p ripple / 40mA max (alarm short)

#### 1 RS-485 Connection

For remote annunciators. Terminals are labeled "RS-485".

**SPR-200 Polarity reversal city tie module (optional)**

**SRM-212/206 Relay Module (optional)**

**System Model:** SFC-200 Series LCD Version Fire Alarm Control Panel

**System Type:** Local, Auxiliary (using SPR-200), Remote Protected Premise Station (using SPR-200 or SFC-201-12DDR or SFC-200-6DDR) Central Station Protected Premises (using SFC-201-12DDR or SFC-200-6DDR)

**Type of Service:** A, M, WF, SS

**Type of Signalling:** Non-Coded

**Applicable Standards:** NFPA 70 and 72, UL-864 Rev. 9

### SRM-212/206 Relay adder module

Must be connected to a listed power-limited source of supply

**Contact rating** NO / NC / 28VDC per contact / 1A resistive load max

**Current consumption** standby 0mA / alarm (SRM-212) 160mA / alarm (SRM-206) 80mA

### SICA-206 Input Class A Converter module

Standby 0mA / alarm 0mA

### SOCA-204 Output Class A Converter module

Standby 0mA / alarm 0mA

### SOCA-202 Output Class A Converter module

Standby 0mA / alarm 0mA

### SSR-212 Smart Relay Module

Must be connected to a listed power-limited source of supply

**Contact rating** NO/NC / 28VDC per contact / 1A resistive load max

**Current consumption** standby 30mA / alarm 140mA

### RAM-300 Remote LCD Annunciator

Standby 16mA / alarm 40mA

### SRAM-208 8 Zone Remote Annunciator

Standby 35mA / alarm 90mA

### Remote Trouble Indicator

Standby 35mA / alarm 35mA

### Polarity reversal and city tie module

**City tie** power limited / 24VDC unfiltered / 250mA max / 14Ohms trip coil

**Polarity reversal** power limited / 24VDC open / 12VDC at 3.5mA / 8.5mA max (shorted)

Polarity reversal supv terminal

24VDC (normal) / -24VDC (supervisory) / 0V (trouble)

Polarity reversal alarm terminal

24VDC (normal) / -24VDC (alarm) / 0V (trouble)

**Current consumption** standby 50mA / alarm 300mA (city tie in use) / alarm 70mA (city tie not in use)

## Appendix D: Power Supply and Battery Calculations (Selection Guide)

Use the form below to determine the required secondary power supply (batteries).

IMPORTANT NOTICE							
The main AC branch circuit connection for Fire Alarm Control Panel must provide a dedicated continuous power without provision of any disconnect devices. Use #12 AWG wire with 600-volt insulation and proper over-current circuit protection that complies with the local codes. Refer to <i>Appendix A</i> for specifications.							
Power Requirements (All Currents are in Amperes)							
Model Number	Description	Qty		Standby	Total Standby	Alarm	Total Alarm
SFC-201-12DDR	Fire Alarm Control Panel, 12 Inp, 4Out with UDACT Using 3K9 resistors		X	0.174	=	0.444	=
SFC-201-12DDR	Fire Alarm Control Panel, 12 Inp, 4Out with UDACT Using active resistors		X	0.104	=	0.394	=
SFC-200-6DDR	Fire Alarm Control Panel, 6 Inp, 2 Out with UDACT Using 3K9 resistors		X	0.142	=	0.312	=
SFC-200-6DDR	Fire Alarm Control Panel, 6 Inp, 2 Out with UDACT Using active resistors		X	0.112	=	0.282	=
SFC-200-6DR	Fire Alarm Control Panel, 6 Inp, 2 Out without UDACT Using 3K9 resistors		X	0.142	=	0.312	=
SFC-200-6DR	Fire Alarm Control Panel, 6 Inp, 2 Out with UDACT Using active resistors		X	0.112	=	0.282	=
SICA-206	Det Class A Converter Adder Module		X	0.000	-0.000	0.000	-0.000
SOCA-204	Sig Class A Converter Adder Module--4 Circuits		X	0.000	-0.000	0.000	-0.000
SOCA-202	Sig Class A Converter Adder Module--2 Circuits		X	0.000	-0.000	0.000	-0.000
SPR-200	Polarity Reversal and City Tie Module		X	0.050	=	0.300 (City Tie in Use)	=
SRM-212	12 Relay Adder Module		X	0.000	=	0.160	=
SRM-206	6 Relay Adder Module		X	0.000	=	0.080	=
SSR-212	Smart Relay Module		X	0.030	=	0.140	=
SRAM-200LCD	Smart Remote Annunciator		X	0.016	=	0.040	=
SRAM-208/216	Remote Annunciator		X	0.035	=	0.090/0.140	=
SRTI-200	Remote Trouble Indicator		X	0.035	=	0.035	=
Two-Wire Smoke Detectors			X	* 0.00011	=	* 0.090	= 0.090
Four-Wire Smoke Detectors			X		=		=
Signal Load (bells, horns, strobes, and etc.)			X				=
Auxiliary Power Supply for Annunciators, etc.					=		=
Total currents (Add above currents)				STANDBY	(A)	ALARM	(B)

\*Assume three Initiating Circuits are in alarm.

Use **0.084** for five minutes of alarm or **0.5** for thirty minutes of alarm as a multiplier figure.

\*Using the Mircom **MPD-65P** 2-wire photoelectric smoke detector.

**Total Current Requirement:**ALARM (B) \_\_\_\_\_ Amps. (Value obtained from column B)

**Battery Capacity Requirement:**

((STANDBY (A) \_\_\_\_\_ ] X [(24 or 60 Hours) \_\_\_\_ ]) + ([ALARM (B) \_\_\_\_\_ ] X [ ' Alarm in Hr.] \_\_\_\_\_ ) = (C) \_\_\_\_\_ AH

**Total Alarm Current:** Must be 6 amperes or less for SFC-200 Series. Indicating Circuits must not exceed 5 amperes.

**Battery Selection:** Multiply (C) by 1.20 to derate battery.

# Warranty and Warning Information

---

## Warning Please Read Carefully

Note to End Users: This equipment is subject to terms and conditions of sale as follows:

### Note to Installers

This warning contains vital information. As the only individual in contact with system users, it is your responsibility to bring each item in this warning to the attention of the users of this system. Failure to properly inform system end-users of the circumstances in which the system might fail may result in over-reliance upon the system. As a result, it is imperative that you properly inform each customer for whom you install the system of the possible forms of failure.

### System Failures

This system has been carefully designed to be as effective as possible. There are circumstances, such as fire or other types of emergencies where it may not provide protection. Alarm systems of any type may be compromised deliberately or may fail to operate as expected for a variety of reasons. Some reasons for system failure include:

#### •*Inadequate Installation*

A Fire Alarm system must be installed in accordance with all the applicable codes and standards in order to provide adequate protection. An inspection and approval of the initial installation, or, after any changes to the system, must be conducted by the Local Authority Having Jurisdiction. Such inspections ensure installation has been carried out properly.

#### •*Power Failure*

Control units, smoke detectors and many other connected devices require an adequate power supply for proper operation. If the system or any device connected to the system operates from batteries, it is possible for the batteries to fail. Even if the batteries have not failed, they must be fully charged, in good condition and installed correctly. If a device operates only by AC power, any interruption, however brief, will render that device inoperative while it does not have power. Power interruptions of any length are often accompanied by voltage fluctuations which may damage electronic equipment such as a fire alarm system. After a power interruption has occurred, immediately conduct a complete system test to ensure that the system operates as intended.

#### •*Failure of Replaceable Batteries*

Systems with wireless transmitters have been designed to provide several years of battery life under normal conditions. The expected battery life is a function of the device environment, usage and type. Ambient conditions such as high humidity, high or low temperatures, or large temperature fluctuations may reduce the expected battery life. While each transmitting device has a low battery monitor which identifies when the batteries need to be replaced, this monitor may fail to operate as expected. Regular testing and maintenance will keep the system in good operating condition.

#### •*Compromise of Radio Frequency (Wireless) Devices*

Signals may not reach the receiver under all circumstances which could include metal objects placed on or near the radio path or deliberate jamming or other inadvertent radio signal interference.

#### •*System Users*

A user may not be able to operate a panic or emergency switch possibly due to permanent or temporary physical disability, inability to reach the device in time, or unfamiliarity with the correct operation. It is important that all system users be trained in the correct operation of the alarm system and that they know how to respond when the system indicates an alarm.

#### •*Automatic Alarm Initiating Devices*

Smoke detectors, heat detectors and other alarm initiating devices that are a part of this system may not properly detect a fire condition or signal the control panel to alert occupants of a fire condition for a number of reasons, such as: the smoke detectors or heat detector may have been improperly installed or positioned; smoke or heat may not be able to reach the alarm initiating device, such as when the fire is in a chimney, walls or roofs, or on the other side

of closed doors; and, smoke and heat detectors may not detect smoke or heat from fires on another level of the residence or building.

- Software*

Most Summit products contain software. With respect to those products, Summit does not warranty that the operation of the software will be uninterrupted or error-free or that the software will meet any other standard of performance, or that the functions or performance of the software will meet the user's requirements. Summit shall not be liable for any delays, breakdowns, interruptions, loss, destruction, alteration or other problems in the use of a product arising out of, or caused by, the software.

Every fire is different in the amount and rate at which smoke and heat are generated. Smoke detectors cannot sense all types of fires equally well. Smoke detectors may not provide timely warning of fires caused by carelessness or safety hazards such as smoking in bed, violent explosions, escaping gas, improper storage of flammable materials, overloaded electrical circuits, children playing with matches or arson.

Even if the smoke detector or heat detector operates as intended, there may be circumstances when there is insufficient warning to allow all occupants to escape in time to avoid injury or death.

- Alarm Notification Appliances*

Alarm Notification Appliances such as sirens, bells, horns, or strobes may not warn people or waken someone sleeping if there is an intervening wall or door. If notification appliances are located on a different level of the residence or premise, then it is less likely that the occupants will be alerted or awakened. Audible notification appliances may be interfered with by other noise sources such as stereos, radios, televisions, air conditioners or other appliances, or passing traffic. Audible notification appliances, however loud, may not be heard by a hearing-impaired person.

- Telephone Lines*

If telephone lines are used to transmit alarms, they may be out of service or busy for certain periods of time. Also the telephone lines may be compromised by such things as criminal tampering, local construction, storms or earthquakes.

- Insufficient Time*

There may be circumstances when the system will operate as intended, yet the occupants will not be protected from the emergency due to their inability to respond to the warnings in a timely manner. If the system is monitored, the response may not occur in time enough to protect the occupants or their belongings.

- Component Failure*

Although every effort has been made to make this system as reliable as possible, the system may fail to function as intended due to the failure of a component.

- Inadequate Testing*

Most problems that would prevent an alarm system from operating as intended can be discovered by regular testing and maintenance. The complete system should be tested as required by national standards and the Local Authority Having Jurisdiction and immediately after a fire, storm, earthquake, accident, or any kind of construction activity inside or outside the premises. The testing should include all sensing devices, keypads, consoles, alarm indicating devices and any other operational devices that are part of the system.

- Security and Insurance*

Regardless of its capabilities, an alarm system is not a substitute for property or life insurance. An alarm system also is not a substitute for property owners, renters, or other occupants to act prudently to prevent or minimize the harmful effects of an emergency situation.

**IMPORTANT NOTE:** End-users of the system must take care to ensure that the system, batteries, telephone lines, etc. are tested and examined on a regular basis to ensure the minimization of system failure.

## Limited Warranty

Summit Systems Technologies warrants the original purchaser that for a period of two years from the date of manufacture, the product shall be free of defects in materials and workmanship under normal use. During the warranty period, Summit Systems Technologies shall, at its option, repair or replace any defective product upon return of the product to its factory, at no charge for labor and materials. Any replacement and/or repaired parts are warranted for the remainder of the original warranty or ninety (90) days, whichever is longer. The original owner must promptly notify Summit Systems Technologies in writing that there is defect in material or workmanship, such written notice to be received in all events prior to expiration of the warranty period.

### International Warranty

The warranty for international customers is the same as for any customer within Canada and the United States, with the exception that Summit Systems Technologies shall not be responsible for any customs fees, taxes, or VAT that may be due.

### Conditions to Void Warranty

This warranty applies only to defects in parts and workmanship relating to normal use. It does not cover:

- damage incurred in shipping or handling;
- damage caused by disaster such as fire, flood, wind, earthquake or lightning;
- damage due to causes beyond the control of Summit Systems Technologies such as excessive voltage, mechanical shock or
- water damage;
- damage caused by unauthorized attachment, alterations, modifications or foreign objects;
- damage caused by peripherals (unless such peripherals were supplied by Summit Systems Technologies);
- defects caused by failure to provide a suitable installation environment for the products;
- damage caused by use of the products for purposes other than those for which it was designed;
- damage from improper maintenance;
- damage arising out of any other abuse, mishandling or improper application of the products.

## Warranty Procedure

To obtain service under this warranty, please return the item(s) in question to the point of purchase. All authorized distributors and dealers have a warranty program. Anyone returning goods to Summit Systems Technologies must first obtain an authorization number. Summit Systems Technologies will not accept any shipment whatsoever for which prior authorization has not been obtained. NOTE: Unless specific pre-authorization in writing is obtained from Summit management, no credits will be issued for custom fabricated products or parts or for complete fire alarm system. Summit will at its sole option, repair or replace parts under warranty. Advance replacements for such items must be purchased.

Note: Summit Systems Technologies's liability for failure to repair the product under this warranty after a reasonable number of attempts will be limited to a replacement of the product, as the exclusive remedy for breach of warranty.

## Disclaimer of Warranties

This warranty contains the entire warranty and shall be in lieu of any and all other warranties, whether expressed or implied (including all implied warranties of merchantability or fitness for a particular purpose) And of all other obligations or liabilities on the part of Summit Systems Technologies neither assumes nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product.

This disclaimer of warranties and limited warranty are governed by the laws of the province of Ontario, Canada.

## Out of Warranty Repairs

Summit Systems Technologies will at its option repair or replace out-of-warranty products which are returned to its factory according to the following conditions. Anyone returning goods to Summit Systems Technologies must first obtain an authorization number. Summit Systems Technologies will not accept any shipment whatsoever for which prior authorization has not been obtained.

Products which Summit Systems Technologies determines to be repairable will be repaired and returned. A set fee which Summit Systems Technologies has predetermined and which may be revised from time to time, will be charged for each unit repaired. Products which Summit Systems Technologies determines not to be repairable will be replaced by the nearest equivalent product available at that time. The current market price of the replacement product will be charged for each replacement unit.

**WARNING:** Summit Systems Technologies recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.

**NOTE:** Under no circumstances shall Summit Systems Technologies be liable for any special, incidental, or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability, or any other legal theory. Such damages include, but are not limited to, loss of profits, loss of the product or any associated equipment, cost of capital, cost of substitute or replacement equipment, facilities or services, down time, purchaser's time, the claims of third parties, including customers, and injury to property.

**SUMMIT MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO ITS GOODS DELIVERED, NOR IS THERE ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, EXCEPT FOR THE WARRANTY CONTAINED HEREIN.**

